

*Chris★Craft*

**Model:  
350-F**

**HI-PERFORMANCE  
THERMOCON MARINE ENGINES  
AND  
OUTBOARD DRIVE**

**(EFFECTIVE SERIAL NO. 620001)**

**OWNER'S MANUAL**

**PART NO. 16.99-08778**

# ENGINE OPER TABLE OF CC

TO ORDER PARTS .....	
Illustration of Engine Plate	
ENGINE SPECIFICATIONS .....	
ADJUSTMENT INFORMATION .....	
Firing Order	
TORQUE SPECIFICATIONS .....	
YOUR NEW CHRIS-CRAFT MARINE ENGINE .....	
Identification	
Use Genuine Chris-Craft Parts	
To Start Engine	
Break-In	
LUBRICATION SYSTEM .....	
Oil Pressure	
Engine Oil Recommendation	
To Change Engine Oil	
Oil Filter	
ELECTRICAL SYSTEM .....	8
Ignition Circuit	8
Ignition Timing	9
Battery	8
Alternator and Voltage Regulator	8
Alternator Maintenance	9
Starting Motor	9
Wiring Diagram	10
FUEL SYSTEM .....	11
Gasoline Recommendation	11
Carburetor & Fuel Lines	11
Fuel Pump	11
Fuel Filter	11
COOLING SYSTEM .....	12
Flow Chart	13
Maintenance	12
Water Temperature	12
VALVES .....	13
ANNUAL LAY-UP .....	14
Before Lifting Boat From Water	14
After Lifting Boat From Water	14
ANNUAL FITTING OUT .....	15
MAINTENANCE SCHEDULE .....	16
Instruments	16


# TO ORDER PARTS

ENGINE MODEL and ENGINE SERIAL NUMBER must be furnished when replacement parts are required.

The model designation (\*) and serial number (\*) will be found stamped into a plate fastened on top of the exhaust manifold.

NOTICE: EARLIER MODELS WILL HAVE THE SERIAL NUMBER STAMPED ON THE SIDE OF EXHAUST MANIFOLD.

## ILLUSTRATION OF ENGINE PLATE

			
<b>MARINE ENGINE</b>			
WHEN ORDERING PARTS SPECIFY MODEL AND ENGINE NUMBER	MODEL    * * * *	FIRING ORDER - - - - -	ENGINE NO.    * * * * *
<b>CHRIS-CRAFT CORPORATION</b>		<b>POMPANO BEACH, FLORIDA U.S.A.</b>	
			USE ONLY HIGH GRADE HEAVY DUTY MARINE ENGINE OIL SAE 30 OR 10W-30.

Order parts from your nearest Chris-Craft dealer or direct from Chris-Craft Corporation, Service Parts Department, Algonac, Michigan being sure to furnish numbers mentioned above.

For the best performance from your engine —  
INSIST ON GENUINE CHRIS-CRAFT PARTS.

Instructions, specifications and illustrations shown are in accordance with experience and product information as developed at time of publication. The right is reserved to make changes at any time without notice.

# HI-PERFORMANCE MARINE ENGINE

## SPECIFICATIONS


### MODEL 350 FLV — (Serial No. 620001)

Horsepower .....	300 @ 5200 RPM
Bore .....	4 inches
Stroke .....	3½ inches
Piston Displacement .....	350 Cubic inches
Type .....	4 cycle, valve-in-head, V-8
Nominal Compression Ratio .....	9.0 to 1
Minimum Recommended Idle Speed .....	650 RPM
Engine Compression Gauge Readings .....	150 P.S.I.
Oil Pressure .....	10 lbs. at idle (approx.) 35 to 45 lbs. max. speed (hot)
Oil Pan Capacity .....	5 qts. & 1 qt. for filter
Carburetion .....	Single four-barrel (Roch. Q-Jet)
Electrical System .....	12 Volt
Spark Plugs .....	AC-MR 43T or Champion RBL-8
Revolutions .....	A maximum cruising speed not in excess of 85% of full throttle RPM is recommended.

# FIRING ORDER

Rotation from  
Outboard Drive End: Counter Clockwise

Firing Order: 1-8-4-3-6-5-7-2



# TORQUE SPECIFICATIONS

(Oiled threads)

Cylinder Head .....	65 ft. lbs.
Connecting Rod .....	45 ft. lbs.
Main Bearings .....	Inner 75 ft. lbs.
	Outer 65 ft. lbs.
Flywheel .....	60 ft. lbs.
Intake Manifold .....	30 ft. lbs.
Exhaust Manifold .....	30 ft. lbs.
Spark Plug .....	15 ft. lbs.

# YOUR NEW CHRIS-CRAFT MARINE ENGINE

Your Chris-Craft Marine Engine with power-plus performance is the product of long-term, skillful engineering combined with careful manufacturing and exhaustive testing. Chris-Craft's years of practical experience in the marine field are packed into every engine

leaving our plant. With reasonable care during operation and a minimum amount of maintenance this engine will deliver a maximum amount of dependable, economical performance and long life.

## IDENTIFICATION

On every engine there is a plate on top of the exhaust manifold giving the model and serial number. This information is important and must be included in all

parts orders and correspondence relating to the engine.

## USE GENUINE FACTORY REPLACEMENT PARTS

All Chris-Craft Marine Engines have special parts designed to give the best performance under conditions found only in marine use. To insure long life and de-

pendable performance we strongly recommend that only factory replacement parts be used. These may be obtained from your Chris-Craft Dealer.

## TO START ENGINE

Before starting the new engine check the oil level in the crankcase. Check fuel in tank and ventilate engine compartment thoroughly. Shift the drive unit to neutral position. Open the throttle to full open, then close to approximately 1/3 open.

With ignition key, turn on switch and engage the starter. Do not engage the starter for prolonged periods. If the engine does not start immediately, investigate the cause of trouble. As soon as the engine starts release the starter. Check to make sure that

oil pressure is present and that cooling water is circulating.

The engine is equipped with an automatic choke. If the engine does not start due to flooding the throttle should be opened fully which will reduce the choking action. The starter should be engaged with throttle opened fully. As soon as engine starts close the throttle.

The engine should be idling below 1000 RPM before shifting into forward or reverse.

## BREAK-IN

It is very important that the engine be broken in properly. All moving parts in the engine are new and have only been run for a few hours while the engine had its final test. Engines must be run carefully in the beginning until all parts are worn in and the engine becomes limber. Only then will it be safe to run the engine fast for sustained periods of time.

Running new engines or engines after a major overhaul at excessively low RPM for long periods should be avoided because it will tend to prolong the break-in period and delay proper seating of piston rings.

During the first twenty hours of operation, the engine should be run at moderate R.P.M. and at varied speeds. Avoid prolonged idle or trolling speed during

this period. These procedures will contribute to a longer engine life.

During the entire life of the engine always run the engine at medium speeds to allow the oil to warm up before running at sustained high speeds. **When coming to the dock after a run always allow the engine to run at moderate speed for three to five minutes before turning off the ignition. This can be done by slowing down several hundred yards before you get to the dock or letting the engine idle after you have docked. This allows the valves to cool down while the water is still circulating thru the engine and will help prevent warped valves.**

# LUBRICATION SYSTEM

## OIL PRESSURE

Form the habit of watching the oil pressure gauge or light. Advance notice of serious trouble is nearly always indicated by oil pressure reading.

Oil pressure should be approximately 10 lbs. at idle speed and 35 to 45 lbs. at maximum speed with the engine hot.

## ENGINE OIL RECOMMENDATION

Chris-Craft Marine Engines should be serviced with oil of good quality to insure smooth operation, freedom from trouble and best engine performance obtainable. A Marine Engine works at maximum capacity

90% of the time while an automobile engine rarely works at its maximum even 10-15% of the time. Therefore, the requirements for a good lubricating oil are far greater in a Marine Engine.

We recommend the use of S.A.E. No. 30 or 10W-40 lubricating oil containing detergents and additives conforming to API service classification SE. It is not recommended that different brands of oil be mixed. Always replenish with the same make and type of oil that is in the crankcase. If it is necessary to change the make of oil, drain the crankcase completely before refilling.

## TO CHANGE ENGINE OIL

The new engine, when shipped, is filled with S.A.E. 10W-40 break-in oil. After fifteen to twenty hours of running, replace with S.A.E. 30 or 10W-40 motor oil and also replace the oil filter. Subsequent oil and filter changes should be made every fifty to one hundred hours, depending on the type of service to which the engine is subjected. An engine used for short runs only will require an oil change more often than an engine used for long runs. During the longer run, the oil attains the proper operating temperature thereby reducing the possibility of contamination.

The best method for removing crankcase oil is with a suction pump. Insert the suction hose over the oil removal tube. Most marine service stations are equipped with special pumps for removing oil, or a suitable oil sump pump (48.28-12948) may be purchased from your Chris-Craft Dealer.

The engine holds approximately five to six quarts of oil with filter. The amount of oil will vary since engines are installed at different angles in different boat models.

## ENGINE OIL FILTER

The full flow oil filter should be replaced in the new engine when the break-in oil is removed after fifteen to twenty hours running. Thereafter, replace the oil filter every 50 to 100 hours depending upon type of service.

Approved oil filter replacements are as follows: Chris-Craft—16.81-08130, AC-(PF-24), WIX (PC55P). If the normal oil pressure decreases at high engine speeds it may be due to a clogged oil filter. Run at reduced engine speed and change the oil filter promptly.

# ELECTRICAL SYSTEM

The engine has a 12 volt electrical system. The starter, alternator, regulator, distributor and coil all have identification affixed denoting the respective manufacturer. These units are warranted and serviced by these manufacturers. Apply directly to the manufacturer's distributor or dealer for warranty or service on these units.

It is important that all electrical connections be periodically inspected. Make certain that the condition of the insulation on all wires is good and all mechanical connections are tight and free from corrosion. In boats operated in salt water it is especially important that all connections be inspected two or three times

each year. If necessary each connection should be taken apart, cleaned with fine sandpaper, given a light coating of CRC or petroleum jelly to retard corrosion and tightly reconnected. Battery terminals should be cleaned often with water and baking soda, coated with petroleum jelly and reconnected. High tension leads must be in good condition. Even a small crack in the insulation might permit oil or moisture to cause a partial ground requiring replacement of the lead. Spraying all of the electrical units, terminals and high tension wires with CRC, or equivalent, at each engine oil change helps to reduce corrosion and damage from dampness.

## IGNITION CIRCUIT

The explosion proof distributor should be inspected every 100 operating hours or not less than every six months. After removing the distributor cap inspect the breaker contacts. If the contacts are grayish in color and are not more than slightly pitted they need not be replaced. We recommend that new breaker contacts be installed when required rather than attempting to reface the old contacts.

Breaker contacts should be set. The ignition timing

should always be reset using a timing light each time the breaker contacts are adjusted and each 100 hours of operation. Inspect all wires and connections and clean up any corrosion at connections if present.

Spark plugs should be cleaned and regapped periodically. Make certain there are no cracks in the porcelain and that the terminals are clean and tight. Any spark plug which is found to have burned or badly worn electrodes should be replaced.

## BATTERY

The battery should be kept near full charge. To check the condition of the battery, specific gravity readings should be taken. For further detail concerning batteries consult your Boat Owner's Manual.

Also keep the battery filled with pure water to the proper level (distilled water is best). Never let the level go below the top of the plates in the battery.

## ALTERNATOR AND VOLTAGE REGULATOR

The engine is equipped with a Yacht Safety Bureau Approved Hi-Output Alternator. The alternator produces alternating current which is changed to direct

current by a self contained rectifier. Alternators have the advantage of charging at low engine RPM which makes them ideal for marine use.

### The following precautions should be observed to prevent damage to the alternator:

1. Engine is wired with a negative ground system. Do not reverse polarity.
2. Do not attempt to polarize alternator. It is unnecessary and could destroy alternator.
3. When using a dockside battery charger disconnect battery terminals. Never use a "fast charger" to supply starting voltage.
4. Be careful not to accidentally ground the field circuit or output terminal on the alternator.
5. Never disconnect battery leads when the engine is running since this will damage the alternator diodes.
6. Be sure all electrical connections are tight. A loose connection can destroy the voltage regulator.



## ADJUSTMENT INFORMATION

### Model 350FLV—(Ser. No. 620001 thru 620184)

Spark Plug, Champion .....	Gap—.028"
Spark Plug, AC <i>M.R. H3T</i> .....	Gap—.035"
Distributor Points (Delco 1112148 DIST.) .....	Gap—.019"
	Dwell—29-31°
Ignition Timing .....	<i>8° BTDC</i> <del>12° BTDC</del> <i>TRANSISTOR</i> <i>ENG INSTALLED</i>

### Model 350FLV—(Ser. No. 620185 thru 620606)

Spark Plug, Champion .....	Gap—.028"
Spark Plug, AC .....	Gap—.035"
Distributor Points (Mallory YL-585-AV DIST.) .....	Gap—.018"
	Dwell—28-30°
Ignition Timing .....	4° BTDC

### Model 350FLV—(Ser. No. 620607)

Spark Plug, Champion .....	Gap—.028"
Spark Plug, AC .....	Gap—.035"
Distributor Points (Mallory YL-585-CV-2 Dual Point DIST.) .....	Gap—.020"
	Dwell—one set 26°
	Total 31-35°
Ignition Timing .....	8° BTDC

## IGNITION TIMING

To set the ignition timing, use a timing light. The torsional damper at the front of the engine is provided with a saw mark, indicating T.D.C. This mark should be aligned with the B.T.D.C. mark on the timing indicator, which is attached to the timing chain cover.

The ignition timing should be rechecked after tightening the distributor hold down to be sure it is properly set. **CAUTION: WHEN SETTING THE IGNITION TIMING, DO NOT LET THE ENGINE IDLE SPEED EXCEED 650 R.P.M.**

## ALTERNATOR MAINTENANCE

Make sure the alternator is mounted securely in place. Check the drive belt tension and alignment carefully, particularly after installation of new belts. Retightening new belts is necessary after a few hours operation or after storage.

NOTE: If the alternator fan can be rotated by pulling

on a fan blade with one finger, the belt is too loose and must be tightened.

The alternator should only be adjusted by authorized service stations which have instruments and information necessary to correctly repair this unit. The voltage regulator is a sealed unit and does not require servicing.


## STARTING MOTOR

No periodic lubrication of the starting motor or solenoid is required. Since the starting motor and brushes cannot be inspected without disassembling the unit,


no service is required on these units between overhaul periods.

# ENGINE WIRING DIAGRAM MODEL 350FLY

NOTE: For 307 G.L.V. 307 G.C.V.  
The Motor Feed 06.63-00049  
To Be Attached To  
Battery Pos. Terminal  
On Solestud



VIEW A



Standard wiring is suitable for voltmeter or alternator indicator light. When using ammeter, see the engine installation recommendations section of this book.

# FUEL SYSTEM

It is very important that the gasoline used meets the requirements for your engine. Use of gasoline which does not meet these requirements can result in burned

valves and pistons, poor engine performance and shorter engine life.

## FUEL RECOMMENDATION

Gasoline used for this engine should be regular marine leaded or low lead gasoline of at least 92 research octane number. (87 antiknock index or number designation 2 as defined by the Cost of Living Council.)

CAUTION: When purchasing gasoline, be very careful not to get research octane confused with antiknock index (or octane number).

The use of marine white or unleaded gasoline should be avoided.



## CARBURETOR & FUEL LINES

The carburetor is warranted and serviced by the manufacturer and his distributors.

It is important that all fuel connections be kept tight and that dirt be kept out of the carburetor. Clean the carburetor flame arrestor regularly.

The carburetor is equipped with non-adjustable high speed jets which require no attention. The idle adjusting needles should be turned to the position where the engine idles smoothest. (650 RPM IN GEAR)

## FUEL PUMP

The mechanical fuel pump furnished with the engine is warranted and serviced by the manufacturer and

his distributors and should be inspected, repaired or replaced periodically as operating conditions warrant.

## FUEL FILTER

The fuel filter is attached to the front of the engine on the right exhaust manifold header. It has an extra large sediment bowl and is equipped with a pleated paper element. The paper element (16.81-00017) (Purolator 64195) should be replaced at least seasonally or as operating conditions warrant.

Before removing the sediment bowl for cleaning be

sure to turn off the fuel line valve to prevent gasoline from spilling in the boat. It is a good suggestion in removing the bowl to loosen it, then slip a plastic bag over the bowl and remove the bag and bowl as a unit thereby preventing gasoline from being spilled into the bilge.

# COOLING SYSTEM

The Thermocon-Develvo marine engine cooling system is a patented arrangement which THERMOstatically CONTROLS temperature at a pre-DEtermined VELOCITY and VOLUME of water. Two water pumps (sea water and circulating), a thermostat and pressure relief valves are the primary units involved.

The sea water is taken in through the strainer on the outboard drive gear housing by a positive displacement pump that is mounted on the left hand side of the engine. This is referred to as the sea water pump. The seawater pump circulates water to the thermostat housing and into two pressure relief valves, one on each exhaust riser. Each valve has a two-pound relief spring. Until such time that the engine is completely filled with water and has built up a two-pound back pressure, all the water from the sea water pump is forced into the thermostat housing leading to the circulating pump inlet, with the exception of a very small quantity that is allowed to pass through small vent holes in the pressure relief valves. This small quantity will go into the exhaust risers and overboard through the exhaust pipe. The reason for these vent holes is to eliminate any air from being trapped in this part of the system.

After the sea water pump has built up a pressure in the engine to two-pounds then the pressure relief valves are forced open by pressure from the positive displacement pump allowing the water to flow out through the exhaust wye collector overboard.

The function of the sea water pump is as follows:

1. to maintain a constant supply of water to the engine circulating system at all times.
2. to help cool and muffle the exhaust pipe.

The circulating system consists of a centrifugal pump mounted on the front of the engine which circulates water through the engine. The pump has one inlet and two outlets. Water from the two outlets is forced through the cylinder block, cylinder heads, and intake manifold to the thermostat housing. The water then makes two passes through the exhaust manifolds and returns to the thermostat housing.

Located at the front end of the intake manifold is a thermostat and thermostat housing. This is a 143° to 165° thermostat. The function of this thermostat is to maintain a constant water temperature from the exhaust manifold water outlet. If the water in passing through the engine has not reached a high enough temperature to open the thermostat, it will return to the inlet of the centrifugal water pump and recirculate through the engine. If, however, the water has reached opening temperature the thermostat will allow a regulated amount of water to flow into the exhaust risers and through the exhaust wye collector overboard. The water which passes through the thermostat is replaced by cool water from the sea water pump thus maintaining controlled engine temperature.

## MAINTENANCE

Normal maintenance for the pumps includes attention to drive belts and hoses, keeping them properly tightened and making replacement when inspection shows signs of deterioration.


## WATER TEMPERATURE

The operating temperature of the thermostatically controlled water cooling system is from 143° to 165°. The temperature sending element should be of such physical dimension as to extend into the water flow

to insure a true temperature reading. Any radical change from this normal temperature would indicate a malfunction in the system.

# WATER COOLING SYSTEM

## Model 350FLV



## VALVES

Good valve action is very important to the efficiency and smoothness of the engine. Engines operated with proper care will require a minimum amount of valve maintenance.

The need for valve service will first be indicated by loss of engine speed, increased fuel consumption and rough idling. A check of the compression in each cylinder is a reliable check of valve condition. The test should be made with all spark plugs removed at cranking speed with wide open throttle and engine

hot. The reading will be approximately 150 P.S.I. A uniform reading on all cylinders is more important than the individual reading of each cylinder. If a low reading is shown in one or more cylinders a little oil on top of the piston will help to determine if the valves are at fault.

This engine is equipped with hydraulic valve lifters for quiet operation. It is important that the oil be kept clean to assure quiet and efficient operation. Hydraulic valve lifters very seldom require adjustment.

## VALVE ADJUSTMENT

With no. 1 piston on top dead center compression stroke, the following valves can be adjusted: intake on cyl. no. 1 - 2 - 5 - 7.

exhaust on cyl. no. 1 - 3 - 4 - 8

Valve adjustment can be made by backing out the adjusting nut until lash is felt at the push rod, then turn in adjusting nut until all lash is removed. This can be determined by checking push rod side play

while turning adjusting nut. When play has been removed, turn adjusting nut in 1 additional turn to place the hydraulic lifter plunger in the center of its travel. No other adjustment is required.

Rotate engine until no. 6 piston is on top dead center compression stroke and adjust the following valves: intake on cyl. no. 3 - 4 - 6 - 8

exhaust on cyl. no. 2 - 5 - 6 - 7

# ANNUAL LAY-UP

In areas where freezing is a problem, preparing the engine becomes a major consideration because of the potential damage from freezing. This does not infer

that lay-ups in more temperate climates are less important or less exacting. A thorough lay-up operation will include the following steps.

## BEFORE LIFTING BOAT FROM WATER

1. Change Oil Filter, drain the engine oil and refill the crankcase. Add Chris-Craft Crankcase Oil Supplement, part number 56.00-20630, in the proportion of 16 ozs. for every four to six quarts of oil.
2. EITHER OF THE FOLLOWING TWO METHODS FOR FOGGING THE ENGINE IS RECOMMENDED
  - a. Add Chris-Craft Fuel Conditioner and Valve Lubricant, part number 56.00-20629, to the gasoline supply in the proportion of 6 oz. to each 7 gallons of gasoline. We suggest running the fuel supply low at the end of the season, thereby, reducing the required amount of Fuel Conditioner. If preferred, the treated fuel may be fed from an auxiliary tank. An outboard motor gasoline tank would serve very well for this purpose. Run the engine for at least fifteen minutes to disperse the Conditioner throughout the engine. The conditioning properties lie in the residue resulting from the combustion of the

Fuel Conditioner, therefore, it is very important to run the engine as directed. After approximately 15 minutes, close the fuel valves at the tank and run the engine until it stalls.

- b. Chris-Craft Fogging Oil in a handy 16 oz. spray can may be ordered from your Chris-Craft Dealer under part number 56.00-00204. The contents of this can is enough for two engines and the directions on the label must be followed.
3. Remove and clean the fuel filter sediment bowl and replace the pleated paper element 16.81-00017 (Purolator 64195)
4. Pull the boat from the water, bow first, to insure complete drainage of the exhaust system. If the boat is lifted vertically, the same result can be accomplished by keeping the bow higher than the stern.

## AFTER LIFTING BOAT FROM WATER

1. Drain the entire cooling system, and flush with fresh water. This is especially important for boats operated in salt water. Drain plugs and valves (painted red) are located as follows:
  - (a) Open drain valves under right and left exhaust risers. (total of four drain valves).
  - (b) Remove drain valves in port and starboard side of cylinder block.  
NOTE: These openings are sometimes blocked with sediment and may require probing with a wire to dislodge the obstruction.  
When all trapped water has been dispelled inject a quantity of glycerine into the pump intake. Again rotate the engine to completely coat the impeller. The glycerine will prevent freeze-up and also aid in priming when the engine is reactivated.
  - (c) Drain the hose running from the outboard drive water intake to the sea water pump inlet.
2. Remove the battery or batteries and arrange to have them charged periodically throughout the inactive period. Wash the exterior of each battery

with a soda solution to remove all traces of corrosion and acid.

3. Seal the flame arrestor against dirt and moisture. This can be done by using an air-tight plastic bag in which to enclose the entire carburetor.
4. Cover the fuel-tank-thru-hull vents, making them airtight.
5. Repaint blemished area with Chris-Craft blue engine enamel which is available in handy "spray-on" cans from your Chris-Craft Dealer.
6. Apply a film of Chris-Craft Oil Supplement on all exposed and unpainted metal surfaces.
7. Remove the distributor cap and oil the advance mechanism. Apply a light coating of Chris-Craft Oil Supplement on the distributor cam. Replace the distributor cap.
8. Spray all electrical connections with CRC or its equivalent.

# MAINTENANCE SCHEDULE

The following maintenance schedule is offered as a suggestion only. Maintenance requirements will vary according to engine usage.

Each time the engine is run:

1. Check oil level in engine and reverse gear. Maintain oil level at mark on dipsticks.
2. Check fuel level, fuel system and exhaust system, by visual inspection.
3. Make sure cooling water is circulating after starting engine by checking flow of water out exhaust pipe and observing temperature gage or indicator light.
4. Battery water should be brought up to level, if necessary.

EVERY 50 RUNNING HOURS:

1. Change oil and filter every 50 to 100 hours depending on type of service.
2. Clean carburetor flame arrestor.
3. Remove fuel filter bowl and replace pleated paper element 16.83-90006 (Carter 30-135S)
4. Clean ventilating valve located in the valve cover each time oil is changed.
5. Correct any fuel, oil or water leaks.

An oil pressure gauge, tachometer, water temperature gauge and voltmeter (or ammeter) should be installed. An electric tachometer is recommended since there is no mechanical tachometer drive on the engine. If an ammeter is desired, the 06.63-08719 wire from the

EVERY 100 RUNNING HOURS (OR NOT LESS THAN EVERY 6 MONTHS):

1. Clean and tightly reconnect all dirty electrical connections.
2. Replace deteriorated rubber hoses.
3. Remove distributor cap and distributor rotor. Put 5 drops medium engine oil on felt at top of center shaft under rotor. Put 1 drop of light engine oil on breaker arm pivot pin. Wipe off excess. Put light film of grease on breaker cam. Wipe off excess. Examine condition of ignition breaker contacts and set gap to proper dimensions.
4. Examine spark plugs. Clean or replace plugs which are dirty or show evidence of burning.
5. Set ignition timing with timing light. 4° B.T.D.C.
6. Examine condition of engine paint. "Aerosol Spray Paint" is available for touchup from your Chris-Craft Dealer.

## INSTRUMENTS

alternator output to the starter solenoid should be removed and discarded. Also the orange wire should be moved from the alternator auxiliary terminal to the output terminal.

# ANNUAL FITTING OUT


1. Replace all drain plugs and close all drain valves.
2. Crank engine and observe to see if the sea pump is primed.
3. Reconnect all hoses loosened during lay-up.
4. Replace and reconnect the battery or batteries, making certain they are adequately charged and filled with water.
5. Inspect and replace all exhaust fittings and hoses if necessary.
6. Remove covering from carburetor or flame arrestor.
7. Uncover fuel tank vents and open fuel valves.
8. Remove excess oil from internal distributor parts.
9. Start the engine. Refer to starting section.



# ENGINE PARTS


## TABLE OF CONTENTS

Partial Engine .....	19
Cylinder Block .....	19
Electrical Ground .....	19
Gasket Set .....	19
Camshaft .....	20, 21
Crankshaft .....	20, 21
Main Bearings .....	20, 21
Pistons and Rings .....	22
Connecting Rods .....	22
Valves and Lifters .....	23, 24
Cylinder Head .....	23, 24
Valve Cover .....	23, 24
Front Cover, Cylinder Block .....	25
Oil Pump and Baffle .....	25
Oil Pan .....	26
Oil Removal Tube .....	27
Oil Filter and Adapter .....	28
Crankshaft Pulleys .....	29
Oil Dipstick and Tubes .....	30
Flywheel Drive Plate .....	30
Flywheel Housing .....	31
Front Mounts (After Ser. No. 620874) .....	32
Front Engine Mount .....	33
Fuel Pump and Fuel Lines .....	34
Fuel Filter .....	35
Inlet Manifold—350 4 Bbl. ....	36
Carburetor 4 Barrel Q-Jet .....	37
Crankcase Vent System Q-Jet Carburetor .....	38
Starter Motor—(with relocated solenoid) .....	39
Starting Motor .....	40
Spark Plug and Cable Supports .....	41
Ignition Coil .....	42
Ignition Distributor .....	43
Ignition Distributor (with Tach Drive) .....	44
Alternator and Voltage Regulator .....	45
Alternator (Optional) .....	46
Thermostat Housing .....	47
Exhaust Manifold and Headers .....	48
Exhaust Riser .....	49
Circulating Water Pump .....	50
Sea Water Pump .....	51
Water Hose System .....	52
Exhaust Wye Cover Plate .....	53



Code No.	Part No.	No. Req'd	Name
<b>PARTIAL ENGINE</b>			
	16.11-30061	1	Engine Assembly—Partial 350 L.H. Rot. NOTE: Partial Engine Consists of Complete Short Block—Inlet Manifold—Cyl. Heads, Water Pump, Oil Pump and Oil Pan.
<b>CYLINDER BLOCK</b>			
	16.11-20050	1	Cylinder Block Assembly—350 NOTE: Cylinder Block Assembly includes fitted pistons, ring assemblies and bearings.
1	16.74-10000	8	Cup plugs 1 $\frac{5}{8}$ " Brass
2	16.74-10001	1	Cup plugs $\frac{3}{8}$ " Brass (rear of block below LH water inlet)
3	16.11-00090	6	Cup plugs $\frac{1}{2}$ " (oil galleries)
4	16.11-00089	1	Cup plugs 2 $\frac{1}{8}$ " (camshaft front bearing hole)
5	16.11-00088	2	Plug 1 $\frac{1}{4}$ " Sq. Socket
6	16.58-10153	1	Pipe Plug $\frac{1}{8}$ " Slotted Head (oil pressure hole)
	16.11-00318	3	Pipe Plug $\frac{1}{4}$ " Sq. Head (oil galleries)
7	16.58-17982	2	Valve Drain $\frac{1}{4}$ " Brass (water drain—each side)
9	16.47-00007	2	Dowel Pin $\frac{1}{4}$ "x $\frac{7}{8}$ " (align timing chain cover to block)
	16.11-00086	2	Dowel Pin $\frac{1}{4}$ "x $\frac{5}{8}$ " (at oil pump flange)
	16.11-00093	2	Dowel Pin $\frac{5}{8}$ " diameter (align front cover)
10	16.11-00092	4	Dowel Pin 5/16"x9/16" (at cylinder deck)
	16.11-00086	1	Dowel Pin $\frac{1}{4}$ "x $\frac{5}{8}$ " (cylinder block to front bearing cap)
<b>ELECTRICAL GROUND</b>			
11	16.44-47486	1	Grounding Stud
	16.41-10005	1	Washer 25/64"x11/16"x1/16"
	16.36-10009	2	Nut $\frac{3}{8}$ "—24 Brass
<b>GASKET SET</b>			
	16.50-00220	1	Complete Gasket Overhaul Set
	16.96-08631	1	Complete Valve Grind Gasket Set

CAMSHAFT CRANKSHAFT MAIN BEARINGS



Code No.	Part No.	No. Req'd	Name
<b>CAMSHAFT</b>			
1	16.11-00807	1	Camshaft Assembly—LH Rot. <b>NOTE:</b> It is very important that special camshaft lubricant be applied liberally to prevent damaging camshaft lobes when new camshaft or valve lifters are installed. This lubricant can be ordered from Chris-Craft using part number 56.00-20630
2	16.11-00753	1	Bearing, Camshaft Rear
3	16.11-00754	2	Bearing, Camshaft No. 3 and 4
4	16.11-00753	1	Bearing, Camshaft No. 2
5	16.11-00752	1	Bearing, Camshaft No. 1
6	16.11-00046	1	Sprocket, Camshaft (L.H. Rot.)
8	16.11-00045	1	Chain, Camshaft (L.H. Rot.)
9	16.11-00086	1	Pin, Camshaft Dowel (Included in Camshaft Assy.)
9A	16.11-00144	3	Bolt, Camshaft 5/16-18x3/4"


Sold As A  
Set Under Part No. 16.96-08642

#### CRANKSHAFT

12	16.11-01029	1	Crankshaft (350 Left Hand Rotation)
13	16.11-00096	1	Pin, Flywheel Dowel
14	16.11-00334	1	Crankshaft Sprocket (Left Hand Rotation)
16	16.11-00098	2	Key, Crankshaft
17	16.51-10027	2	Seal, Crankshaft (Left Hand Rotation)


#### MAIN BEARINGS

18	16.11-00389	1	Main Bearing Set—Rear (Incl. Upper & Lower)
19	16.11-00327	4	Main Bearing Set—All except (Upper & Lower)
18	16.11-00390	1	Main Bearing Set—Rear (Inc. Upper & Lower .001 US)
18	16.11-00391	1	Main Bearing Set—Rear (Incl. Upper & Lower .002 US)
18	16.11-00392	1	Main Bearing Set—Rear (Incl. Upper & Lower .010 US)
18	16.11-00393	1	Main Bearing Set—Rear (Incl. Upper & Lower .020 US)
19	16.11-00395	4	Main Bearing Set—All except Rear (Upper & Lower .001 US)
19	16.11-00396	4	Main Bearing Set—All except Rear (Upper & Lower .002 US)
19	16.11-00397	4	Main Bearing Set—All except Rear (Upper & Lower .010 US)
19	16.11-00398	4	Main Bearing Set—All except Rear (Upper & Lower .020 US)
21	16.11-00375	5	Main Bearing Cap Bolt (2 in ea. main bearing cap)
20	16.11-00376	5	Main Bearing Cap Stud (front, inter, Center & Rear)
	16.11-00407	6	Main Bearing Cap Bolt (Short-Outer)



PISTONS, RINGS, CONNECTING RODS

Code No.	Part No.	No. Req'd	Name
<b>PISTON AND RINGS</b>			
1	16.11-01030	8	Piston w/Pin Std. (350)
1	16.11-01031	8	Piston w/Pin .030 O.S. (350)
2	16.11-00692	8	Ring Unit Std. (350)
2	16.11-00693	8	Ring Unit .010 O.S. (350)
2	16.11-00694	8	Ring Unit .030 O.S. (350)
1	16.11-00845	8	Piston w/Pin .030 O.S. (350)
<b>CONNECTING RODS</b>			
3	16.11-00300	8	Connecting Rod Assembly (includes rod, bolts, cap & nuts)
5	16.11-00303	16	Connecting Rod Bolt
6	16.11-00418	16	Connecting Rod Nut
7	16.11-00305	8	Connecting Rod Bearing Std. (includes upper & lower halves)
7	16.11-00306	8	Connecting Rod Bearing—.001 U.S. (includes upper & lower halves)
7	16.11-00380	8	Connecting Rod Bearing—.002 U.S. (includes upper & lower halves)
7	16.11-00381	8	Connecting Rod Bearing—.010 U.S.
7	16.11-00382	8	Connecting Rod Bearing—.020 U.S.



Code No.	Part No.	No. Req'd	Name
----------	----------	-----------	------

### VALVES (350)

1	16.11-00535	8	Valve, Exhaust
2	16.11-00530	8	Valve, Inlet
3	16.11-00322	8	Spring, Inlet Valve
3	16.11-00703	8	Spring, Exhaust Valve
4	16.11-00153	16	Shield, Valve Stem Oil
5	16.11-00152	16	Seal, Valve Stem Oil
6	16.11-00041	8	Rotator, Exhaust Valve
7	16.11-00273	16	Cap, Valve Spring
8	16.11-00433	32	Key, Valve Stem

### VALVE LIFTERS & ROCKER ARMS

9	16.11-00399	16	Valve Lifter Assembly—Hydraulic
---	-------------	----	---------------------------------

**NOTE:** It is very important that special camshaft lubricant be applied liberally to prevent damaging camshaft lobes, when new camshaft or valve lifters are installed. This lubricant can be ordered from Chris-Craft using part number 56.00-20630.


10	16.11-00038	16	Push Rod
11	16.11-00495	16	Arm, Valve Rocker
12	16.11-00043	16	Ball and Nut, Rocker Arm
	16.11-00151	16	Stud, Rocker Arm—.003 O.S.
	16.11-00228	16	Stud, Rocker Arm—.013 O.S.

### CYLINDER HEAD

14	16.11-00887	2	Cylinder Head—Only
15	16.50-00147	2	Gasket, Cylinder Head (Stainless Steel)
16	16.11-00010	14	Bolt, Cylinder Head—Long
17	16.11-00022	4	Bolt, Cylinder Head—Medium
18	16.11-00003	16	Bolt, Cylinder Head—Short
19	16.58-10164	2	Plug, ½" Pipe Countersunk Head—Brass


### VALVE COVER

20	16.11-01032	2	Valve Cover
	16.11-00336	2	Cap, Oil Filter
21	16.50-00184	2	Gasket, Valve Cover
23	16.11-00500	8	Bolt, Valve Cover
	16.92-07761	1	Decal, Fuel
	16.92-08719	2	Decal, Model (350)
	16.92-07601	1	Decal, Rotation—Left Hand




**CYLINDER BLOCK FRONT COVER**

Code No.	Part No.	No. Req'd	Name
<b>CYLINDER BLOCK FRONT COVER</b>			
1	16.11-00540	1	Cover, Crankcase Front End
2	16.50-00175	1	Gasket
3	16.11-00806	1	Seal, Front Cover
4	16.11-00167	10	Screw and Lockwasher
	16.11-00546	as req'd	Pointer, Timing (350 Left Hand Only)




Code No.	Part No.	No. Req'd	Name
<b>OIL PUMP AND BAFFLE</b>			
1	16.11-00156	1	Pump, Oil
2	16.11-00238	1	Screen, Oil Pump
	16.11-00445	1	Shaft, Oil Pump To Distributor
	16.11-00446	1	Retainer, Oil Pump Shaft
3	16.11-00274	1	Bolt, Oil Pump
4	16.11-00802	1	Baffle, Oil Pan
5	16.11-00297	5	Nut, Oil Baffle
		5	Washer, Spacer—Under Baffle






OIL PAN

Code No.	Part No.	No. Req'd	Name
<b>OIL PAN</b>			
1	16.11-01034	1	Oil Pan
2	16.11-00945	4	Screw and Lockwasher Ass'y.
3	16.11-00167	14	Screw and Lockwasher Ass'y.
4	16.51-10032	1	Seal, Oil Pan—Rear
5	16.50-00183	1	Gaskets—Oil Pan—Side
6	16.51-10031	1	Seal, Oil Pan—Front (Early Engines)
6	16.51-10037	1	Seal, Oil Pan—Front (Later Engines)




OIL REMOVAL TUBE

Code No.	Part No.	No. Req'd	Name
<b>OIL REMOVAL TUBE</b>			
1	16.95-00205	1	Oil Removal Tube Ass'y.
2	16.99-00267	1	Tube End
3	16.11-00765	1	Gasket
4	16.14-00622	1	Gasket
5	16.14-00621	1	Hollow Screw



OIL FILTER AND ADAPTER

Code No.	Part No.	No. Req'd	Name
<b>OIL FILTER AND ADAPTER</b>			
1	16.81-08130	1	Oil Filter
2	16.72-08128	1	Nut, Lock
3	16.72-08127	1	Nipple
4	16.20-08259	1	Adapter
5	16.58-10151	2	Plug, Pipe 1/8-27
6	16.50-08155	1	Gasket, Oil Adapter
7	16.50-08352	1	Gasket, Oil Adapter Ring
8	16.41-10001	2	Washer, Flat
9	16.30-00078	2	Screw, Cap 5/16-18x1 3/4
10	16.99-08126	1	Valve, By-Pass
11	16.58-10168	1	Plug, Pipe 3/4-14



Code No.	Part No.	No. Req'd	Name
<b>CRANKSHAFT PULLEYS</b>			
1	16.11-00717	1	Torsional Damper
2	16.11-00103	1	Pulley, Crankshaft
3	16.20-00171	1	Pulley, Sea Pump Drive
4	16.11-00101	1	Washer, Flat
5	16.11-00206	1	Washer, Lock
6	16.30-01403	1	Screw, Cap 7/16-20x2½
7	16.42-00004	3	Washer, Lock
8	16.30-00038	3	Screw, Cap 3/8-24x3½


Code No.	Part No.	No. Req'd
----------	----------	-----------

1	16.11-00718	1
2	16.57-07524	1
3	16.57-00038	1

Name

**OIL DIPSTICK AND TUBES**

Gage Ass'y.—Oil Level  
 Tube, Oil Gage—Upper  
 Tube, Oil Gage—Lower




Code No.	Part No.	No. Req'd
----------	----------	-----------


1	16.11-00526	1
2	16.11-00158	6
3	16.11-00157	6
4	16.99-08575	1
5	16.42-00004	3
6	16.11-00169	3

Name

**FLYWHEEL AND DRIVE PLATE**


Flywheel Assembly  
 Washer 7/16 Toothlock  
 Bolt, Flywheel  
 Plate, Drive  
 Washer, Lock 3/8  
 Bolt, Drive Plate






FLYWHEEL HOUSING

Code No.	Part No.	No. Req'd	Name
<b>FLYWHEEL HOUSING</b>			
1	16.21-08624	1	Housing, Flywheel
2	16.41-00006	7	Washer, Flat
3	16.30-00130	5	Screw, Cap Hex Hd. $\frac{3}{8}$ -16x1 $\frac{3}{8}$
4	16.42-00004	7	Washer, Lock $\frac{3}{8}$
5	16.30-00132	2	Screw, Cap Hex Hd. $\frac{3}{8}$ -16x1 $\frac{1}{2}$
6	16.44-08154	6	Stud—Attach Outdrive Adapter
6	16.41-00008	6	Washer, Flat
6	16.42-00007	6	Washer, Lock
6	16.36-00080	6	Nut, 7/16-14
7	16.70-08502	1	Plate, Flywheel Cover
8	16.30-00544	5	Screw, Cap Hex Hd. $\frac{1}{4}$ -20x1 $\frac{1}{2}$ Cad. Pl.
9	16.42-00011	5	Washer, Lock $\frac{1}{4}$
10	16.99-00188	2	Clamp, Wire—Attach Wire Harness



**FRONT MOUNTS (AFTER SER. NO. 620874)**


No. Code	No. Part	Req'd No.	Name
<b>FRONT MOUNTS (AFTER SER. NO. 620874)</b>			
1	16.20-00174	1	Mount Bracket—Right Side
1	16.20-00175	1	Mount Bracket—Left Side
2	16.42-00004	6	Washer, $\frac{3}{8}$ Lock
3	16.30-00128	6	Screw, Cap $\frac{3}{8}$ -16x1 $\frac{1}{4}$
4	16.93-08042	2	Mount



FRONT ENGINE MOUNT


Code No.	Part No.	No. Req'd.	Name
<b>FRONT ENGINE MOUNT</b>			
1	16.20-07652	2	Bracket, Front Engine Mount
2	16.42-00004	6	Washer, Lock $\frac{3}{8}$
3	16.30-00130	4	Screw, Cap Hex Hd. $\frac{3}{8}$ -16x1 $\frac{3}{8}$
	16.30-00132	2	Screw, Hex Hd. $\frac{3}{8}$ -16x1 $\frac{1}{2}$ (Attach Regulator Brk.)
4	16.72-07657	2	Washer, Shoulder
5	16.93-05808	2	Mount, Rubber
6	16.20-07692	2	Housing, Front Engine Mount
7	16.30-00545	2	Screw, Cap Hex Hd. 5/16-18x1 $\frac{3}{4}$ Cad. Pl.
8	16.42-00003	2	Washer, Lock 5/16 Cadmium Plate
9	16.41-05840	2	Washer, Mount Retaining
10	16.39-00006	2	Nut, Lock $\frac{5}{8}$ -11 Elastic Stop
11	16.36-07694	4	Nut, Hex 1-16
13	16.41-07695	4	Washer, Flat
14	16.20-00099	2	Adapter, Engine Mount
15	16.30-00020	2	Screw, Cap Hex Hd. $\frac{1}{4}$ -20x1 $\frac{3}{4}$
16	16.41-00002	4	Washer, Flat
17	16.70-08749	4	Lug, Keeper
18	16.57-08758	2	Spacer, Steel
19	16.42-00001	2	Washer, Lock $\frac{1}{4}$
20	16.36-00000	2	Nut, Lock $\frac{1}{4}$ -20






FUEL PUMP AND FUEL LINES

Code No.	Part No.	No. Req'd	Name
<b>FUEL PUMP AND FUEL LINES</b>			
1	16.83-00012	1	Pump, Fuel
2	16.59-00068	1	Elbow—Pump Outlet $\frac{3}{8}$ " Fuel Line
3	16.50-00074	1	Gasket, Fuel Pump
4	16.11-00167	2	Screw & Lockwasher
5	16.11-00025	1	Plate, Fuel Pump
6	16.50-05756	1	Gasket, Pump Plate
7	16.11-00024	1	Rod, Pump Push
8	16.59-00068	1	Elbow—Pump Inlet
9	16.41-00006	2	Washer Flat
10	16.42-00004	2	Washer, Lock $\frac{3}{8}$
11	16.30-00132	2	Screw, Hex Hd. $\frac{3}{8}$ -16x1 $\frac{1}{2}$
	16.57-58771	1	Fuel Line—Pump To Filter $\frac{3}{8}$ x9
	16.95-00203	1	Fuel Line Assy—Pump To Carb




Code No.	Part No.	No. Req'd	Name	FUEL FILTER
1	16.81-00014	1	Filter Assy., Fuel	
2	16.58-10056	1	Elbow, Street 1/4 (Optional)	
3	16.99-00033	1	Valve, Fuel Shut-Off 1/4 Npt	
4	16.81-00013	1	Element, Filter	
5	16.81-00018	1	Case, Filter	
6	16.30-00060	2	Screw, Cap Hex Hd. 5/16-18x5/8	
7	16.42-00002	2	Washer, Lock 5/16	
8	16.81-00015	1	Cover, Filter	
9	16.59-00068	1	Elbow, Fuel 3/8Tx1/4 Mpt	
10	16.81-00016	1	Gasket, Filter	



INLET MANIFOLD—350 4 BBL.


Code No.	Part No.	No. Req'd	Name
<b>INLET MANIFOLD 350 4 BBL.</b>			
1	16.11-01017	1	Manifold, Inlet
2	16.50-00165	1	Gasket, Manifold—Rear
3	16.58-10160	1	Plug, Brass 3/8-18
4	16.30-00126	12	Screw, Cap Hex Hd. 3/8-16x1 1/8
5	16.50-00213	2 (opt.)	Gasket, Manifold—Side—"Optional"
5	16.50-00158	2 (opt.)	Gasket, Manifold—Side—"Optional"
6	16.50-00168	1	Gasket, Manifold—Front
	16.70-08531*	2	Lifting Bracket

NOTE: Items 2, 5, and 6 may be purchased as a kit; 16.50-00232




CARBURETOR 4 BARREL Q-JET

Code No.	Part No.	No. Req'd	Name
			<b>CARBURETOR 4 BARREL Q-JET</b>
1	16.82-40014	1	Carburetor
	16.96-08654	AR	Repair Kit, Carb
2	16.30-00601	2	Screw, Cap Hex Hd. 5/16-18x1¼ Cad. Pl.
3	16.11-01033	1	Insulator Gasket—Carb
4	16.30-00037	2	Screw, Cap Hex Hd. 5/16-18x3¾ Cad. Pl.
5	16.41-00005	4	Washer, Flat Cad. Pl.
6	16.50-08361	opt.	Gasket, Flame Arrestor
7	16.82-00034	1	Arrestor Assy., Flame
8	16.39-00010	1	Nut, Lock
9	16.44-00010	1	Stud, Flame Arrestor
10	16.11-00788	1	Choke, Thermostat & Rod
11	16.11-00702	1	Screw, Choke
12	16.11-00790	1	Clip, Choke Rod
11	16.11-00702	1	Screw, Choke
12	16.11-00790	1	Clip, Choke Rod




CRANKCASE VENT SYSTEM Q-JET CARB.

Code No.	Part No.	No. Req'd	Name
<b>CRANKCASE VENT SYSTEM Q-JET CARB.</b>			
1	16.11-00552	2	Grommet, Vent System
2	16.11-00401	1	Connector, Vent Hose
3	16.54-10087	1	Hose $\frac{5}{8} \times 12\frac{1}{2}$
4	16.54-08362	1	Hose, Molded
5	16.11-00786	2	Clamp, Vent Hose
	16.55-38391	opt.	Clamp, Vent Hose
6	16.99-00072	1	Valve, Vent




STARTING MOTOR (WITH RELOCATED SOLENOID)

Code No.	Part No.	No. Req'd	Name
<b>STARTING MOTOR (WITH RELOCATED SOLENOID)</b>			
1	16.61-00048	1	Starting Motor
2	16.11-00662	1	Bolt, Starter—Outboard
3	16.11-00661	1	Bolt, Starter—Inboard
4	16.32-00134	2	Screw
5	16.41-00001	2	Washer, Flat
6	16.42-00000	2	Washer, Lock
7	16.36-00015	2	Nut
8	16.61-00053	1	Solenoid, Starter
9	16.70-00159	1	Bracket, Solenoid
10	16.30-00002	1	Screw, Cap ¼-20x5/8
11	16.42-00011	1	Washer ¼ Lock
12	16.42-00002	1	Washer 5/16 Lock
13	16.30-00060	1	Screw, Cap 5/16-18x5/8
14	16.70-08429	1	Bracket, Starter Support
15	16.42-00001	1	Washer, ¼ Lock
16	16.36-00000	1	Nut, Hex ¼-20
17	16.63-08399	1	Wire, Solenoid To Starter
18	16.63-08146	1	Wire, Solenoid To Ground



STARTING MOTOR


Code No.	Part No.	No. Req'd	Name
<b>STARTING MOTOR</b>			
1	16.61-00042	1	Motor, Starting—L.H. Rotation
2	16.11-00661	1	Bolt, Starter—Inboard
3	16.11-00662	1	Bolt, Starter—Outboard
4	16.42-00001	1	Washer, Lock ¼
5	16.36-00000	1	Nut, Hex ¼-20
6	16.70-08429	1	Bracket, Starter Support
7	16.42-00004	1	Washer, Lock 5/16
8	16.30-00058	1	Screw, Hex Hd. 5/16-18x½
9	16.61-00047	AR	Solenoid



**SPARK PLUG & CABLE SUPPORTS**


Code No.	Part No.	No. Req'd	Name
<b>SPARK PLUG &amp; CABLE SUPPORTS</b>			
1	16.11-00172	2	Support, Spark Plug Cable—Side
2	16.11-00171	2	Support, Spark Plug Cable—Lower
3	16.11-00167	4	Screw & Lockwasher Assy.
<b>SPARK PLUGS AND CABLES</b>			
	16.62-08737	8	Spark Plug —Gap .035"
	16.63-08743	1	Ignition Cable Set
	16.63-08744	AR	Ignition Cable Set (With Tach Drive Distributor)






IGNITION COIL

Code No.	Part No.	No. Req'd	Name
<b>IGNITION COIL</b>			
1	16.64-00034	1	Coil, Ignition
2	16.30-00128	1	Screw, Hex Hd. $\frac{3}{8}$ -16x1 $\frac{1}{4}$ Coil To Rear Cover
3	16.42-00004	1	Washer, Lock $\frac{3}{8}$
4	16.36-00004	1	Nut $\frac{3}{8}$ -16
5	16.70-08521	1	Bracket, Ignition Coil
6	16.42-00000	1	Washer, Lock No. 10
7	16.32-00129	1	Screw, Mach. Fil. Hd. No. 10-32x1 $\frac{3}{4}$




**SPARK PLUG & CABLE SUPPORTS**

<b>Code No.</b>	<b>Part No.</b>	<b>No. Req'd</b>	<b>Name</b>
<b>SPARK PLUG &amp; CABLE SUPPORTS</b>			
1	16.11-00172	2	Support, Spark Plug Cable—Side
2	16.11-00171	2	Support, Spark Plug Cable—Lower
3	16.11-00167	4	Screw & Lockwasher Assy.
<b>SPARK PLUGS AND CABLES</b>			
	16.62-08737	8	Spark Plug —Gap .035"
	16.63-08743	1	Ignition Cable Set
	16.63-08744	AR	Ignition Cable Set (With Tach Drive Distributor)




**IGNITION DISTRIBUTOR**

Code No.	Part No.	No. Req'd	Name
<b>IGNITION DISTRIBUTOR</b>			
1	16.64-00048	1	Ignition Distributor—Complete
3	16.69-00100	1	Cap, Distributor
4	16.92-00036	1	Decal, Distributor (L.H. Rot.)
5	16.69-00042	1	Rotor
6	16.69-00040	1	Condensor
7	16.69-00039	1	Ignition Points
8	16.11-00344	1	Clamp, Distributor
9	16.30-00120	1	Screw, Cap Hex Hd. $\frac{3}{8}$ -16x $\frac{3}{4}$
10	16.50-00162	1	Gasket, Distributor




IGNITION DISTRIBUTOR (WITH TACH DRIVE)

Code No.	Part No.	No. Req'd.	Name
		Optional	<b>IGNITION DISTRIBUTOR (WITH TACH DRIVE)</b>
1	16.64-00049	1	Ignition Distributor, Complete
2	16.69-00148	1	Cap, Ign. Distributor
3	16.69-00149	1	Rotor, Ign. Distributor
4	16.69-00039	2	Points, Ignition
5	16.69-00040	1	Condensor
6	16.11-00344	1	Clamp, Distributor
7	16.30-00120	1	Screw, Cap $\frac{3}{8}$ -16x $\frac{3}{4}$
8	16.50-00162		Gasket, Distributor




Code No.	Part No.	No. Req'd	Name
<b>ALTERNATOR AND VOLTAGE REGULATOR</b>			
1	16.65-00026	1	Alternator Assembly Prestolite
2	16.70-00106	1	Bracket, Alternator Adjusting
3	16.41-00024	1	Washer, Flat
4	16.42-00002	1	Washer, Lock 5/16
5	16.30-00066	1	Screw, Cap Hex Hd. 5/16-18x1
6	16.57-08778	1	Spacer, Alternator
7	16.30-00156	1	Screw, Cap Hex Hd. 3/8-16x3—Alt. To Left Header
8	16.57-08777	1	Spacer, Alternator
8	16.42-00004	1	Washer, Lock 3/8
10	16.63-08625	1	Wire, Noise Filter To Alternator
11	16.69-00102	1	Filter, Noise
12	16.70-08009	1	Bracket, Regulator
13	16.12-00285	1	Clamp, Wire
14	16.60-00031	1	Voltage Regulator Prestolite
15	16.41-00001	2	Washer, Flat
16	16.43-00009	2	Washer, Toothlock
17	16.35-00031	2	Screw No. 10
	16.97-07552	1	Belt 1/2" "V"—Alternator
	16.20-08540	1	Pulley, Alternator




ALTERNATOR (OPTIONAL)

Code No.	Part No.	No. Req'd	Name
<b>ALTERNATOR (OPTIONAL)</b>			
1	16.65-00039	1	Alternator and Regulator Assy.
2	16.70-00106	1	Bracket, Adjusting
3	16.41-00024	1	Washer, Flat
4	16.42-00002	1	Washer, Lock
5	16.30-00066	1	Screw, Cap 5/16-18x1
6	16.72-20017	1	Pulley, Alternator
7	16.63-08167	1	Wire, Alternator To Coil Pos.
8	16.36-00080	1	Nut, 7/16-14
9	16.42-00007	1	Washer, Lock
10	16.57-00076	1	Spacer 29/64x5/8x1
11	16.57-00077	1	Spacer 29/64x5/16x1
12	16.30-00230	1	Screw, Cap 7/16-14x3
	16.97-07552	1	Belt



THERMOSTAT HOUSING


Code No.	Part No.	No. Req'd	Name
<b>THERMOSTAT HOUSING</b>			
1	16.20-00140	1	Housing, Thermostat
2	16.30-00144	2	Screw, Cap Hex Hd. $\frac{3}{8}$ -16x2 $\frac{1}{4}$
3	16.70-07546	AR	Bracket, Front Lifting—Optional
4	16.50-00096	1	Gasket, Thermostat Housing
5	16.99-08329	1	Thermostat
6	16.58-T7120	1	Nipple, Hose $\frac{3}{4}$ x1 $\frac{1}{2}$
7	16.50-08333	1	Gasket, Thermostat Cap
8	16.20-08496	1	Cap, Thermostat Housing
9	16.30-00004	4	Screw, Hex Hd. $\frac{1}{4}$ -20x $\frac{3}{4}$
10	16.42-00001	4	Washer, Lock $\frac{1}{4}$



EXHAUST MANIFOLD AND HEADERS


Code No.	Part No.	No. Req'd	Name
<b>EXHAUST MANIFOLD AND HEADERS</b>			
1	16.20-07056	2	Manifold, Exhaust
2	16.50-05748	2	Gasket Set, Exh. Manifold To Head
3	16.58-10160	as req'd	Plug, Pipe C' Sunk Hd. $\frac{3}{8}$ -18 Brass
4	16.72-36264	as req'd	Stove, Auto Choke Heater
5	16.50-05944	2	Gasket, Header To Manifold
6	16.20-00161	1	Header, Exh. Manifold—Left
7	16.92-07588	1	Plate, Name—L.H. Rotation Only
7	16.92-07745	1	Plate, Thermocon—Develvo
8	16.33-00000	12	Screw No. 4x $\frac{1}{4}$ Nickle Plate
9	16.30-00172	12	Screw, Cap Hex Hd. $\frac{3}{8}$ -16x4
10	16.42-00004	20	Washer, Lock $\frac{3}{8}$
11	16.30-00132	8	Screw, Cap Hex Hd. $\frac{3}{8}$ -16x1 $\frac{1}{2}$
12	16.20-00119	1	Header, Exh. Manifold—Right
13	16.55-38478	as req'd	Clip, Hose—Sea Water Hose






**EXHAUST RISER**

Code No.	Part No.	No. Req'd	Name
			<b>EXHAUST RISER</b>
1	16.20-08288	1	Riser, Exhaust—Left Side
1	16.20-08289	1	Riser, Exhaust—Right Side
2	16.58-10168	2	Plug, Pipe Soc. Hd. 3/4 Brass
3	16.58-17120	2	Nipple, Hose 3/4x1 1/2
4	16.44-37595	4	Stud 3/8x9 1/4 Stainless Steel
5	16.50-05944	2	Gasket, Exh. Riser To Exh. Manifold
6	16.58-10172	2	Plug, Pipe Soc. Hd. 1" Brass
7	16.42-00004	12	Washer, Lock 3/8
8	16.30-00449	4	Screw, Cap Soc. Hd. 3/8-16x2 1/4
9	16.58-17982	4	Valve, Drain 1/4 Npt
10	16.50-07596	2	Gasket, Riser To Deflector
11	16.20-07593	2	Deflector, Exh. Elbow
12	16.50-07597	2	Gasket, Deflector To Elbow
13	16.20-07605	2	Elbow, Exhaust
14	16.30-00546	4	Screw, Cap Hex Hd. 3/8-16x1 3/4 Cad. Pl.
15	16.36-30000	4	Nut, Hex 3/8-24 Stainless Steel
16	16.42-00001	4	Washer, Lock 1/4
17	16.50-00073	2	Gasket, Copper Asbestos
18	16.32-40001	6	Screw, Machine Fil. Hd. 1/4-20x7/8
19	16.22-07532	2	Housing, Pressure Relief Valve
21	16.99-07346	2	Valve, Pressure Relief
22	16.50-07290	2	Gasket, Relief Valve Housing
23	16.58-10164	2	Plug, Pipe Soc. Hd. 1/2 Brass



CIRCULATING WATER PUMP


Code No.	Part No.	No. Req'd	Name
<b>CIRCULATING WATER PUMP</b>			
1	16.11-00742	1	Pump Assy, Cir. Water (Not Serviced)
2	16.11-00077	1	Gasket, Pump L.H.
3	16.11-00078	1	Gasket, Pump R.H.
4	16.30-00136	3	Screw, Cap Hex Hd. $\frac{3}{8}$ -16x1 $\frac{3}{4}$
5	16.30-00152	1	Screw, Cap Hex Hd. $\frac{3}{8}$ -16x2 $\frac{3}{4}$
6	16.11-00815	1	Pulley, Water Pump
7	16.42-00002	4	Washer, Lock 5/16
8	16.30-00061	4	Screw, Hex Hd. 5/16-24x $\frac{5}{8}$



SEA WATER PUMP

Code No.	Part No.	No. Req'd	Name
			<b>SEA WATER PUMP</b>
1	16.80-18344	1	Pump and Pulley Assy. (Early Models)
1	16.80-18346	1	Pump and Hub Assy. (Later Models)
	16.80-90168	A.R.	The Following Repair Kits are Available for Service
	16.80-90155	A.R.	Pump Body, Shaft and Hub Ass'y.
	16.80-90049	A.R.	Seal and Seat
	16.80-90049	A.R.	Impeller
2	16.80-90156	1	Pulley (Early Models)
	16.70-00152	1	Pulley (Later Models)
	16.30-00744	4	Screw, Cap 5/16-18x1/2 Attach Pulley
	16.42-00003	4	Washer, Lock
3	16.30-00074	2	Screw, Cap 5/16-18x1 1/2
4	16.42-00002	2	Washer, Lock
5	16.41-00024	2	Washer, Flat
6	16.57-08776	2	Spacer, Sea Pump
7	16.95-00196	1	Bracket Ass'y.
8	16.42-00004	4	Washer, Lock
9	16.30-00126	1	Screw, Cap 3/8-16x1 1/8
10	16.30-00120	1	Screw, Cap 3/8-16x3/4
11	16.30-00132	2	Screw, Cap 3/8-16x1 1/2
12	16.70-00117	1	Bracket, Alternator Mount

SHERWOOD Pump Kit  
9959K



Code No.	Part No.	No. Req'd	Name
<b>WATER HOSE SYSTEM</b>			
1	16.54-00011	1	Hose, Molded
	16.55-38480	2	Clamp
2	16.54-10100	1	1"x3½"
	16.55-37124	2	Clamp
3	16.54-00018	1	Hose, Molded
	16.55-37124	2	Clamp
4	16.54-10053	4	Hose 1¼x9"
	16.55-37304	8	Clamp
5	16.54-00014	2	Hose, Molded
	16.55-37124	4	Clamp
6	16.54-10026	1	Hose 1"x2¼"
	16.55-37124	2	Clamp
7	16.58-90004	1	Tee, Water
8	16.54-10098	1	Hose 1"ID.x11"
	16.55-37124	2	Clamp, Hose
9	16.54-08016	1	Hose, Molded
	16.55-37124	2	Clamp, Hose
10	16.95-00201	1	Tube and Tee Ass'y.

Code No.	Part No.	No. Req'd	Name
----------	----------	-----------	------

**EXHAUST WYE COVER PLATE**

The Following Cover Plate Assembly Is Used In Conjunction With Straight Thru Exhaust

	16.95-00233	1	Cover Plate Assy.—Consists of the Following 7 Items
1	16.70-20171	1	Cover Plate
2	16.44-30016	4	Stud $\frac{3}{8} \times 1\frac{3}{4}$
3	16.41-00026	4	Washer, Flat
4	16.42-00005	4	Washer, Lock
5	16.36-30000	4	Nut, $\frac{3}{8}$ -24
6	16.50-08135	1	Gasket
7	16.39-08394	4	Nut $\frac{3}{8}$ -16 Lock

**OUTDRIVE  
OPERATION AND PARTS  
AQUAMATIC 270 AND 270T**

**MODEL 350FLV**

**OUTBOARD DRIVE SECTION**

This Portion Of The Engine Operators Manual Is Devoted Entirely To The Aquamatic 270 and 270T Outboard Drive and Has Been Reprinted From The Aquamatic 270 and 270T Outboard Drive Instruction Book By Permission From Volvo Penta, Goteborg, Sweden.




Fig. 1 Outboard drive models 270 and 270T

- |     |                                 |     |                              |
|-----|---------------------------------|-----|------------------------------|
| 1.  | Steering rod                    | 14. | Exhaust outlet with trim tab |
| 2.  | Rubber block                    | 15. | Anti-cavitation plate        |
| 3.  | Cooling-water pipe              | 16. | Oil filler hole              |
| 4.  | Exhaust hose                    | 17. | Gear casing                  |
| 5.  | Exhaust pipe on mounting collar | 18. | Oil dipstick                 |
| 6.  | Mounting collar                 | 19. | Steering rod                 |
| 7.  | Hole for transport bracket      | 20. | Hydraulic tank               |
| 8.  | Zinc plate                      | 21. | Motor for hydraulic pump     |
| 9.  | Locating pin                    | 22. | Lever for control valve      |
| 10. | Retaining pawl                  | 23. | Attachment for control cable |
| 11. | Water intakes                   | 24. | Air nipple                   |
| 12. | Zinc ring                       | 25. | Lift cylinder                |
| 13. | Electromechanical lift          | 26. | Trim cylinder                |

## CONTENTS

<b>Description</b> . . . . .	2
<b>Running Instructions</b>	
Controls . . . . .	4
Running in shallow water . . . . .	5
Running in reverse . . . . .	6
The trim of the boat . . . . .	6
Adjustment of steering rods in case of twin engine installation . . . . .	7
Adjusting for deviation from course . . . . .	7
Trailing . . . . .	8
<b>Periodical Servicing</b>	
Maintenance scheme . . . . .	9
Checking the oil level in outboard drive . . . . .	9
Checking the oil level in hydraulic pump . . . . .	10
Changing the oil in outboard drive . . . . .	10
Greasing the drive shaft bearing and steering bearings . . . . .	11
Checking the anti-corrosion devices . . . . .	12
Removing and fitting the propeller . . . . .	13
Adjusting the retaining pawl and control cable . . . . .	14
Connecting up gear control cable, 270T . . . . .	15
General inspection . . . . .	15
Preparing the unit for laying up . . . . .	16
<b>Electrical wiring diagrams for drives 270 and 270T</b> . . . . .	17
<b>Internal Power Trim 270T, Hydraulic function layout.</b> . . . . .	18
<b>Technical Data</b> . . . . .	19
<b>Adjustment from L.H. to R.H. propeller</b> . . . . .	20



## DESCRIPTION

### Outboard drive models 270 and 270T

The Aquamatic outboard drive models 270 and 270T are second to none when it comes to performance, dependability and toughness.

The outboard drive is flexibly mounted on a collar bolted to the outside of the boat transom. Drive 270T is equipped with Internal Power Trim, which means that the drive can be hydraulically trimmed in and out from the boat operator's seat for optimum performance, and can also be tilted up. Drive 270 has electromechanical lift for tilting up the drive.

All exposed parts are made of corrosion-resistant material. Zinc electrodes protect the drive unit from damage by corrosion caused by galvanic currents. Exhaust gases and cooling water are taken through the collar and drive whose channels are treated with special protection paint. The engine is flexibly suspended in the mounting collar through the flywheel casing.

Power is transmitted from the engine via a double universal joint to the bevel gears for "Forward", "Reverse" and "Neutral". The cone clutch in the shift mechanism ensures smooth and quiet engagement. The cone clutch, which is patented and of the type "Silent Shift", has power-assisted disengagement so that very small transmission forces are required for shifting. The friction cones, which are included in the cone clutch, are self-adjusting.

The propeller gear is of a special bevel type which provides the drive with very quiet operation and makes continuous running in either direction of rotation possible. This means that either a left-hand or right-hand propeller can be used.

A feature of the drive 270T is the Internal Power Trim which enables the boat operator to trim and tilt the unit for optimum boat performance irrespective of load. When running in shallow water, the drive can be partly tilted to "Beach". This means that the boat can be manoeuvred both "Forward" as well as "Reverse" with the drive partly tilted up. The hydraulic system is so designed that the drive can be fully relied upon to tilt up should it unexpectedly strike some obstacle under the water when the boat is running forward. Safety valves in the hydraulic system open with overloading, and this prevents the drive from damage. The hydraulic system is self-venting.

The patented design of the retaining pawl on drive 270 is fully to be relied upon to tilt up should it unexpectedly strike some obstacle under the water when the boat is running forward.

Rapid manoeuvring in "Reverse" in an emergency can be carried out on both the 270 and 270T drives at speed up to about 15 knots without the possibility of the drive "floating up".

## DESCRIPTION




Fig. 2. Cross-section through outboard drives

- |                          |                                 |                           |
|--------------------------|---------------------------------|---------------------------|
| 1. Hydraulic tank        | 18. Oil dipstick                | 35. Water intake          |
| 2. Oil filler hole       | 19. Gear                        | 36. Propeller gear        |
| 3. Motor for pump        | 20. Cone clutch                 | 37. Water intake          |
| 4. Steering rod          | 21. Upper gear housing          | 38. Oil strainer          |
| 5. Piston, lift cylinder | 22. Shift mechanism             | 39. Rubber bellow         |
| 6. Air nipple            | 23. Gear                        | 40. Trim cylinder         |
| 7. Control lever         | 24. Shift fork                  | 41. Piston, trim cylinder |
| 8. Lift cylinder         | 25. Vertical drive shaft        | 42. Exhaust bellow        |
| 9. Control cable         | 26. Oil filler hole             | 43. Hose                  |
| 10. Steering rod         | 27. Intermediate housing        | 44. Supporting rubber pad |
| 11. Lift                 | 28. Trim tab                    | 45. Drive shaft           |
| 12. Lubricating nipple   | 29. Lower gear housing          | 46. Lift yoke             |
| 13. Steering yoke        | 30. Retaining pawl              | 47. Vibration damper      |
| 14. Rubber block         | 31. Release rod, retaining pawl | 48. Rubber bellow         |
| 15. Universal joint      | 32. Mounting collar             | 49. Oil strainer          |
| 16. Steering casing      | 33. Circulation pump            |                           |
| 17. Input gear           | 34. Oil drain                   |                           |

# RUNNING INSTRUCTIONS

## CONTROLS

Described below are the MV single type or MT twin lever control systems with synchronized throttle and shift systems.




Fig. 3. MV with casing for single engine installation. Side mounting.

1. Control lever
2. Neutral throttle knob (pulled out axially)




Fig. 4. Type MT Twin for twin engine installation. Top mounting.

- N = Neutral position  
F = Forward position  
R = Reverse position  
T = Throttle


**Note.** The engine must never be started while the outboard drive is tilted up. For drive 270 there is a warning lamp for the electromechanical lift which lights red as soon as the drive is wholly or partly tilted up. Outboard drive 270T has a trim indicator which shows the exact angle of the drive unit at all times. **When the trim indicator indicates "Tilt", the engine must not be started** until the drive is tilted down to "Trim" or "Beach".

### MANOEUVERING THE INTERNAL POWER TRIM, 270T

Drive model 270T can be manoeuvred to "Trim" and "Beach" while underway by manoeuvring the toggle control switch. The trim indicator shows the exact angle of the drive, see Fig. 5. The drive must not be tilted to "Tilt" while the engine is running, nor must the engine be started with the drive at "Tilt".

**NOTE.** The drive may not be manoeuvred while "Reverse" gear is engaged.

## RUNNING INSTRUCTIONS



### A. Trim

The drive is manoeuvrable while underway for optimum performance.

### B. Beach

The drive is manoeuvrable within "Beach" while underway at low speed and idling, in order to be able to run in shallow water. Once the drive has been adjusted to this position, "Forward" and "Reverse" can be engaged and the speed increased.

### C. Tilt

**The engine must not be started or driven while the drive is within the tilt area.** "Tilt" is intended to be used when the boat is moored in shallow water or when being transported on a trailer.

Fig. 5. Trim, Beach, Tilt, drive 270T

## RUNNING IN SHALLOW WATER 1)

### OUTBOARD DRIVE MODEL 270

When running in shallow water at low speed with great risk of contacting the bottom, it is recommended as an extra safety measure that the retaining pawl for the outboard drive is released with the drive lift. NOTE, Running "Reverse" cannot be carried out with the retaining pawl released. Release the retaining pawl as follows:

Move the control switch to the "Up" position until the warning lamp lights up and then keep the switch in this position for another 2-4 seconds. This reduces the risk of damage to the propeller and outboard drive if they come into contact with the bottom.

1) Normally the outboard drive kicks up automatically if it strikes an object in the water.

## RUNNING INSTRUCTIONS

### OUTBOARD DRIVE MODEL 270T

If the boat is to be run in shallow water and there is risk of contacting the bottom, the engine speed should be cut back to idling and the drive lifted to "Beach" in order to eliminate possible damage to the propeller. Then the engine speed can be stepped up. "Trim" is marked in green on the trim indicator. "Beach" is white and "Tilt" red on the indicator.

If the drive has been lifted to the borderline between the white and red fields on the trim indicator, the boat speed should be low. **If the drive has been lifted so that the pointer on the trim indicator points to the red field, the engine must not be driven.**

## RUNNING IN REVERSE

### OUTBOARD DRIVE MODEL 270

Running "Reverse" can only be carried out when this drive is fully down and the retaining pawl has locked the drive in this position. The warning lamp indicating lifted outboard drive must always be off before running in reverse.

### OUTBOARD DRIVE MODEL 270T

Running "Reverse" can be carried out without hindrance with this drive at "Trim" or "Beach". The drive can be operated fully, and thus the boat can be manoeuvred in "Reverse", with the drive adjusted to "Trim" or "Beach".

## THE TRIM OF THE BOAT

In order to ensure top performance for the boat, the normal position of the anti-cavitation plate on the outboard drive should be parallel with the bottom of the boat.

The normal angle for the transom is  $78^{\circ}$  and the angle between the outboard drive and the transom is adjustable on drive 270 by moving the adjusting pin to one of the three alternative holes (see Fig. 6). Normally the best position for the outboard drive is with the adjusting pin in hole 2.

The angle between the 270T outboard drive and transom is infinitely adjustable from the boat operator's seat while underway. The trim indicator shows the trim position on the indicator green field. In order to reach maximum speed more

## RUNNING INSTRUCTIONS

quickly or to counteract "stern-heavy" tendencies, the drive should be trimmed in all the way. This means that the trim indicator pointer should point to the bottom of the green field on the indicator. If the maximum speed hull position is such that the boat has a tendency to be "nose-heavy", the drive should be trimmed out so that the pointer moves to "Beach".

In order to attain the maximum speed hull position more rapidly and also to improve the boat's running in the case of certain boat types, it may be advisable to fit Volvo Penta trimming flaps.



Fig. 6. Range of use for adjusting pin. Drive 270.

1. Position to counteract "nose-heavy" tendency
2. Neutral position
3. Position to counteract "stern-heavy" tendency




Fig. 7. Angle between drives in case of twin installation

### ADJUSTMENT OF STEERING RODS IN CASE OF TWIN ENGINE INSTALLATION

For optimum propeller efficiency, it is important to adjust the angle of the outboard drives so that the meeting point between the wash from the two propellers is well behind the boat. The angle between the outboard drives increases with deeper V-bottom. See "A", Fig. 7. If the angle is too small, this will often result in propeller cavitation.

## RUNNING INSTRUCTIONS

Fine adjustment of this angle can be carried out by means of the link between the two drive steering rods.

## ADJUSTING FOR DEVIATION FROM COURSE

The outboard drive is fitted with a combined exhaust outlet and trim tab, see Fig. 8. This trim tab can be turned to counteract any tendency towards deviation from course in the steering while underway. Check course deviation with the steering wheel in its neutral position and at cruising speed.

The trim tab is adjusted when necessary by loosening the lock screw (2, Fig. 8) and turning the **trailing edge** of the trim tab **towards** the course deviation. Tighten the lock screw and then test-run the boat. Repeat adjustment if necessary until the best courseholding is obtained with the steering wheel in the neutral position.




Fig. 8.

1. Trim tab
2. Lock screw
3. Transport bracket

## TRAILING

When the boat is being towed on a trailer, the outboard drive should be raised as far as it will go. In order to prevent the drive from shaking down from its tipped-up position, the drive is supplied with a transport bracket (3, Fig. 8). The transport bracket is fitted as follows:

Place the bracket handle in the yoke recess for the locating pin, press together the lower part of the bracket so that both the pins can be located in the mounting collar holes just above the locating pin as shown in Fig. 8.

## PERIODICAL SERVICING

### MAINTENANCE SCHEME

The servicing procedures in the maintenance scheme below are numbered and these numbers refer to the description on the following pages.

Point	Operation	To be carried out:		
		Every 14 days	After 50 <sup>1)</sup> hours running	After 100 <sup>1)</sup> hours running
	<b>PERIODICAL SERVICING</b>			
1	Checking the oil level in outboard drive	•		
2	Checking the oil level in hydraulic pump (270T)	•		
3	Changing the oil in outboard drive			•
4	Greasing the drive shaft bearing and steering bearings		•	
5	Checking the anti-corrosion devices	•		
	<b>GENERAL SERVICING INSTRUCTIONS</b>	To be carried out according to the intervals given under the respective points or when necessary		
6	Removing and fitting the propeller			
7	Adjusting the retaining pawl and connecting up the gear control cable, drive 270			
8	Connecting up gear control cable, drive 270T			
9	Carry out general inspections			
10	Preparing the unit for laying up			

1) Or once each season, whichever occurs first.

#### 1. Checking the oil level in outboard drive

**Check the oil every 14 days** by using the dipstick (1, Fig. 10) in the cover over the upper gear housing. This check must be carried out while the outboard drive is in its lowered position. The oil dipstick should not be screwed in when the oil level is checked.

The oil level should be within the field on the lower flat part of the dipstick. The correct oil grade viscosity is shown in the table on page 11. Fill up through the dipstick hole.



## PERIODICAL SERVICING

### 2.

#### Checking the oil level in hydraulic pump, drive 270T

**Check the oil level in the hydraulic pump every 14 days** by using the dipstick (1, Fig. 9) on top of the tank. Observe great care when carrying out this check that no foreign particles drop down into the tank.

The oil level should be within the field on the flat part of the dipstick.

When necessary top up through the oil filler hole (2, Fig. 9) to the correct level with oil which meets the requirements for "Automatic Transmission Fluid Type F". The designation for the oil is ATF Type F, or in cases of exception, Type A or Dexron, if Type F is not available. **NOTE. Ordinary engine oil must not be used.**




Fig. 9. Hydraulic tank

- 1. Oil dipstick
- 2. Oil filler hole

### 3.

#### Changing the oil in outboard drive

**Change the lubricating oil after every 100 hours running** or at least once each season. Drain off the old oil by removing the plug (2, Fig. 10). The dipstick (1) should be unscrewed so that the oils runs out more easily.

Fill up with oil through the oil filler hole (4). Use the oil scavenging pump and hose nozzle supplied with the tool kit (extra accessories). The drive should be in its tilted-up position when oil is being filled.

After filling up, screw the oil filler plug (4) into position again and lower the drive completely.

Check the oil level by following the instructions in point 1 and fill up if required. Make sure that the washers under the plugs and dipstick are in good condition.

**NOTE.** Never allow the oil level to be above the MAX mark on the dipstick.

## PERIODICAL SERVICING




Fig. 10. Drive 270

1. Oil dipstick    3. Grease nipple, steering shaft    5. Lubricator, steering rod bearing  
 2. Drain hole    4. Oil filler hole    (inside mounting collar)

Quality	Viscosity	Oil capacity
Engine oil Multigrade Service MS	SAE 10W/30 or 20W/40	2 1/4 US qts. (2.2 litres) <sup>1)</sup>

1) Capacity is approx. 2 1/2 US qts. (2.5 litres) with 4" extension.

### 4.

#### Greasing the drive shaft bearing and steering bearings

**After every 50 hours running** the lubricating points mentioned below must be greased with multipurpose grease:

The drive shaft bearing in the flywheel housing is greased by filling the grease nipple with grease and screwing it in all the way.

The steering shaft bearing is greased through the grease nipple (3, Fig. 10) by using a grease gun. Force in so much that it seeps out at the wear washer.

The steering rod bearing is greased through the lubricator (5, Fig. 10) on the inside of the mounting collar. Force in so much grease that it seeps out at the bearing.

## PERIODICAL SERVICING




Fig. 11. Zinc ring



Fig. 12. Zinc plate, drive 270

### 5. Checking the anti-corrosion devices

**Check how much the zinc electrodes have been corroded at least every 14 days.** When about 50% of the original size has been corroded away, replace the electrodes as follows:

#### ZINC RING

Remove the propeller and spacer ring with deflector ring (see point 6 "Removing and fitting the propeller") and remove the Philips screws retaining the zinc ring (Fig. 11).

Scrape the contact surface against the bearing housing clean and fit a new zinc ring. Make sure that there is good metallic contact between the zinc ring and the propeller housing.

#### ZINC PLATE

Unscrew the zinc plate which is fitted under the mounting collar (see Fig. 12). Clean the contact surfaces and fit a new zinc plate. NOTE. The drive 270T has two zinc plates, one on each side of the trim cylinder.

**NOTE. Do not paint the zinc ring or zinc plate.**

### 6. Removing and fitting the propeller

1. Knock up the tabs on the lock washer (2, Fig. 13) for the propeller cone.
2. Unscrew the propeller cone (1) with the help of a screwdriver which is pushed in through the hole in the propeller cone. Then pull off the propeller. Note the spacer ring inside the propeller.
3. Clean the propeller shaft and apply graphite grease, or equivalent, to the shaft.




Fig. 13. Changing propeller

4. **Check that the new propeller has the same size and markings as the earlier unit.**
5. Fit the propeller. **NOTE.** The spacer ring and deflector ring should be fitted between the propeller and the gear housing.

**NOTE. Lock the propeller cone by staking all the teeth on the lock washer.**

If the teeth of the lock washer do not fit in the middle of the cone recess, unscrew the cone and move the lock washer one spline position on the propeller shaft.

## SERVICING

### 7.

#### Adjusting the retaining pawl and connecting up the gear control cable, drive 270

Check once each season, and adjust when necessary, the position of the locking rod against the retaining pawl (A, Fig. 14) and also the position of the push rod B) for lift disengagement of the retaining pawl. Adjust as follows:




Fig. 14. Adjusting retaining pawl, drive 270

1. Remove the protective cover (12, Fig. 14) on the upper gear housing so that the shift mechanism is accessible. Move the control lever to the neutral position.
2. Disconnect the gear control cable "dice" (9) from the lever (8) and the yoke (11) from the gear lever.
3. Loosen the locknut for the yoke (11) and turn the yoke on the gear rod (10) thread so that at the connection with the gear lever the push rod (6) goes into such a position that it just contacts (without pressure) the pawl at "A". Secure the yoke (11) in this position with the locknut.
4. Adjust the gear cable "dice" (9) so that it can easily be moved into the hole on the lever (8) and secure it in this position. Move the control lever to the "Forward" position and check that the corner "C" does not contact the intermediate housing. Fit the cover over the gear shift mechanism.
5. **Press the drive forward, against the adjusting pin,** and check the position of the push rod (3). The upper part (2) of the rod should be level with the yoke at "B". This is to enable the lift (1) to disengage the retaining pawl (5) when tilting up. Adjust the length of the push rod if necessary by loosening the locknut and turning the upper part of the rod (2).

### 8.

#### Connecting up gear control cable, drives 270 and 270T

In those cases where the drive has been removed from the boat and is to be re-fitted, the gear control cable must be connected to the drive shift mechanism as follows:

1. Move the control lever at the boat operator's seat to neutral position.
2. Remove the protective cover (12, Fig. 14) over the shift mechanism. Move the shift mechanism lever to neutral position.
3. Push the gear control cable in as far as it can go and then pull it out fully in order to check for play. Then push in the cable to half the length of the measured play. Screw on the "dice" so far that its pin fits in the lever on the shift yoke. Lock the "dice" with the locknut on the gear control cable.
4. Check that the "dice" and the gear rod (10, Fig. 14) are properly adjusted by moving the control lever to "Forward", "Neutral" and "Reverse" while checking at the same time that the "dice" and gear rod do not jam in their bearings. Adjust if necessary.  
Check to make sure that the corner "C" (Fig. 14) does not contact the intermediate housing.
5. Lock the "dice" to the lever with washer and split pin.

### 9.

#### Carry out general inspection

General inspection of the outboard drive must be carried out after every 100 hours running or at least once each season. Clean the outside of the drive and touch up any damaged paintwork. Paint the underwater parts of the drive and also the cooling water intake channels with anti-fouling paint (must not include copper or mercury).

**NOTE. Do not paint the zinc ring or zinc plate.**

At the same time check for oil leakage and ensure that the rubber bellows are in good condition and that there is no abnormal wear on the links for the control mechanism.

For drive 270T, the Internal Power Trim should also be checked to make sure that there is no leakage at connections or joints.

## SERVICING

### 10.

#### Preparing the unit for laying up

Even insignificant corrosion on precision-machined parts can result in a serious deterioration in the condition of these parts.

If the outboard drive is to remain idle for a longer period than one month, we recommend that it should be given protective treatment as described below.

#### PROTECTIVE TREATMENT

Drain off the oil from the drive and fill up with preservative oil (for example, Shell Ensis Oil 20 or similar). NOTE. The hydraulic system on drive 270T does not require protective treatment. First clean the drive externally with fresh water and then with kerosene or similar solvent. Remove all marine growth and deposits. Then touch up any of the paintwork that may be damaged. **NOTE. Do not paint the zinc ring and zinc plate.** Protect the outboard drive externally by applying anti-rust oil.

If the outboard drive is dismantled from the boat, a cover has to be mounted in the rubber bellows and on the stub shaft in the flywheel housing.

#### PREPARING FOR USE AGAIN

Drain off the preservative oil from the outboard drive. Fill up with oil (see "Servicing", point 3).

Clean the outboard drive externally from rust-proofing oil and replace the zinc ring and zinc plate on the outboard drive, see "Servicing", point 5.

Carefully check the bellows for damage and re-tighten all hose clips. If the drive has been removed, make sure when re-fitting that the bellows and hoses are correctly fitted. Adjust the control cable and retaining pawl, see "Servicing", point 7 for drive 270 and point 8 for drives 270 and 270T.

Paint the underwater parts of the outboard drive and the cooling water intake channels with anti-fouling paint (must not include copper or mercury).

# Electrical wiring diagrams for drives 270 and 270T




Fig. 15. Wiring diagrams

## COMPONENTS

1. Key switch
2. Switch
3. Relay
4. Electric motor
5. Push rod, lift unit
6. Motor protector
7. Switch
8. Warning lamp
9. Trim indicator
10. Trim indicator sender
11. Starter motor
12. Revolution counter

## CABLE MARKINGS

Mark	Color	sq.mm	AWG
A	Ivory	6.0	9
A'	Ivory	2.5	13
A''	Ivory	1.5	15
B	Black	1.5	15
C'	Red (+)	2.5	13
C''	Red (+)	1.5	15
C*	Red	6.0	9
D	Green	1.5	15
D*	Green	2.5	13
D**	Green	6.0	9
F	Yellow	1.5	15
G	Brown	1.5	15
H	Blue	2.5	13
H*	Blue	6.0	9
H**	Blue	1.5	15



# Internal Power Trim, 270T

## Hydraulic function layout




Fig. 16. Hydraulic function for Internal Power Trim, outboard drive 270T

- |                             |  |
|-----------------------------|--|
| 1. Motor                    | 15. Lift cylinder                        |
| 2. Tank                     | 16. Safety valve                         |
| 3. Relief valve, lifting    | 17. Piston, lift cylinder                |
| 4. Return tank              | 18. Lift yoke                            |
| 5. Check valve for lifting  | 19. Control valve, closes when reversing |
| 6. Drain tank, filtered oil | 20. Control lever                        |
| 7. Pump                     | 21. Hose                                 |
| 8. Check valve for lowering | 22. Contact face, trim cylinder – drive  |
| 9. Strainer                 | 23. Rubber bellow                        |
| 10. Relief valve, lowering  | 24. Piston, trim cylinder                |
| 11. "Beach" valve           | 25. Trim cylinder                        |
| 12. Hose                    | 26. Hose                                 |
| 13. Venting nipple          | 27. Ball valve                           |
| 14. Safety release valve    | 28. Ball valve                           |

## TECHNICAL DATA

Type designation . . . . .	Aquamatic 270
Reduction ratios, total, "Forward" and "Reverse" . . .	1.61:1/270 B 1.89:1/270 C 2.15:1/270 D
Type designation . . . . .	Aquamatic 270T
Reduction ratios, total, "Forward" and "Reverse" . . .	1.61:1/270 TB 1.89:1/270 TC 2.15:1/270 TD
Shift mechanism . . . . .	"Silent Shift" self-adjusting cone
Maximum propeller diameter . . . . .	16"
Tip-up angle, drive 270 . . . . .	0°–60°
Tip-up angle, drive 270T	
Trim position . . . . .	–4° to +5°
Beach position . . . . .	5°–30°
Tilt position . . . . .	–30° –60°
Lift unit, type	
drive 270 . . . . .	Electromechanical
drive 270T . . . . .	Hydraulic
Lubricating system . . . . .	Circulation pump for oil supply to all lubricating points
Oil capacity, outboard drive, approx. . . . .	2 1/4 US qts. (2.2 litres)
Oil capacity between max. and min. marks, approx. . . . .	1/4 pint (0.15 litre)
Oil quality . . . . .	Multigrade Service MS
Oil viscosity . . . . .	SAE 10W/30 or 20W/40
Oil capacity, hydraulic system drive 270T, approx. . . . .	1 1/2 US qts. (1.5 litres)
Oil quality, hydraulic system drive 270T . . . . .	Automatic Trans- mission Type F, A1) or Dexron1)

1) Only if type F is not available.


## Adjustment for change from L.H. to R.H. propeller

The gears in the outboard drive are designed to operate under load in either direction of rotation, for use with either left-hand or right-hand propeller, although the standard unit is assembled to use left-hand propeller.

In the standard unit, for use with left-hand propeller, the lower clutch-and-gear functions as the forward drive gear. If it is desired to use a right-hand propeller, as required for the starboard unit of a pair, the linkage of the shifting mechanism may be reversed by a simple change in the assembly, whereupon the upper gear will become the forward drive gear. The procedure then is as follows:

1. Remove the cover from the gear mechanism.
2. Move the gear control rod from locating "A" as shown in Fig. 17 to locating "B".

Location of gear rod for use with right-hand propeller



Standard location of gear rod for use with left-hand propeller


Fig. 17

By reference to Fig. 17, it will be observed that in both positions of the gear rod (A and B), the cable from the shift control lever has a "push" motion for engaging the forward gear. Check and adjust the shift linkage according to "Servicing", point 7, page 14.

## AQ-DRIVE UNIT 270 CONNECTING PARTS

THE PARTS LISTED BELOW ARE INTERCHANGEABLE WITH VOLVO OUTDRIVES


Code No.	Chris-Craft Part No.	Description	Qty.				
				47	16.14-00462	Washer	2
				48	16.14-00019	O-ring	1
1	16.14-00485	Shield	1	49	16.14-00151	Rubber hose	1
2	16.14-00429	Steering yoke	1	50	16.14-00152	Hose clamp	2
3	16.14-00321	Grease nipple	1	51	16.14-00030	Hose with rubberbellows	1
4	16.14-00315	V-ring	1	52	16.14-00512	Clamp	1
5	16.14-00026	Bushing	2	53	16.14-00033	Hose clamp	1
6	16.14-00001	Stud	2	54	16.14-00034	Packing	1
7	16.14-00023	Bearing bolt	2	55	16.14-00252	Screw	6
8	16.14-00024	Washer	2	56	16.14-00035	Packing	6
9	16.14-00322	Nut	2	57	16.14-00253	Washer	6
10	16.14-00022	Bushing, lower	1	58	16.14-00254	Nut	6
11	16.14-00427	Bushing, upper	1	59	16.14-00529	O-ring	4
12	16.14-00319	Protecting cap	1	60	16.90-00035	Ball bearing	1
13	16.14-00055	Bushing	1	61	16.99-00066	Circlip	2
14		Emblem	1	62	16.14-00041	Seal ring	1
15		Drive Screw	2	63	16.99-00065	Circlip	1
16	16.14-00241	Allen screw	2	64	16.90-00034	Ball bearing	1
17	16.14-00002	Rubber seal	1	65	16.99-00067	Circlip	1
18		Bolt	4	66	16.51-10018	Seal ring	1
19	16.14-00006	O-ring	1	67	16.21-08153	Primary shaft housing	1
20	16.14-00028	Exhaust bellow	1	68		Gasket	1
21	16.14-00494	Ring	9	69	16.30-00570	Plug	1
22	24.00-00064	Hose clamp	2	70	16.14-00380	Catch	1
23	16.14-00356	Rubber bend	1	71	16.72-08105	Primary shaft	1
24	16.14-00363	Washer	1				
25	16.14-00255	Plug	1				
26	16.14-00034	Packing	1				
27	16.14-00370	Zinselectrode	1				
28	16.14-00371	Allen Screw	2				
29	16.14-00008	Setting pin	1				
30	16.14-00009	Nut	2				
31	16.14-00010	Bearing pin	2				
32	16.14-00011	Allen screw	2				
33	16.14-00012	Washer	2				
34	16.14-00013	Clamping ring kit	1				
35	16.14-00014	Rubber ring	2				
36	16.14-00015	Screw	6				
37	16.14-00016	Lockwasher	3				
38	16.14-00017	Rubber cushion	1				
39	16.14-00459	Gasket	2				
40	16.14-00460	Washer	2				
41	16.14-00461	Nut	2				
42	16.14-00430	Steering lever	1				
43	16.14-00374	Bolt	1				
44	16.14-00375	Washer	1				
45	16.14-00379	Water pipe grommet	1				
46	16.14-00020	Nut	2				



## AQ-DRIVE UNIT 270 UPPER GEAR UNIT

THE PARTS LISTED BELOW ARE INTERCHANGEABLE WITH VOLVO OUTDRIVES

Code	Chris-Craft						
No.	Part No.	Description	Qty.				
				44	16.14-00407	Shim	A.R.
					16.14-00408	Shim	A.R.
					16.14-00409	Shim	A.R.
1	16.14-00390	Upper gear unit	1				
2	16.14-00391	Housing	1	45	16.14-00078	Shaft	1
3	16.14-00464	Stud	2	46	16.14-00325	Sliding sleeve	1
4	16.14-00392	Cover	1	47	16.14-00081	Spring	1
5	16.14-00051	Screw	1	48	16.14-00082	Washer	1
6	16.14-00052	Gasket	1	49	16.14-00080	Lock ring	1
7	16.14-00086	Bolt	3	50	16.14-00077	Needle bearing	4
8	16.14-00431	Hollow screw	1	51	16.14-00262	Spacer ring	2
9	16.14-00393	O-ring	1	52	16.14-00263	Spacer ring	1
10	16.14-00394	Gasket	1	53	16.14-00083	Lock ring half	2
11	16.14-00432	Gear set	1	54	16.14-00084	Nut	1
12	16.14-00328	Double bearing unit	1	55	16.14-00326	Gear mechanism	1
13	16.14-00465	Peg	1	56	16.14-00093	Bearing housing	1
14	16.14-00502	Roller bearing	1	57	16.14-00094	Eccentric piston	1
15	16.14-00503	Roller bearing	1	58	16.14-00327	Sliding shoe	1
16	16.14-00195	O-ring	2	59	16.14-00097	Spring	1
17	16.14-00063	Shim	A.R.	60	16.14-00102	Steel ball	1
	16.14-00064	Shim	A.R.	61	16.14-00098	Spring	1
18	16.14-00389	Seal ring	1		16.14-00436	Spring	2
19	16.14-00433	Lock ring	1	62	16.14-00095	Lock wire	1
20	16.14-00396	Head washer	1	63	16.14-00096	Bolt	1
21	16.14-00066	O-ring	1	64	16.14-00099	Shim	1
22	16.14-00397	Shim	A.R.	65	16.14-00103	Seal ring	1
	16.14-00398	Shim	A.R.	66	16.14-00101	Lock pin	1
	16.14-00399	Shim	A.R.	67	16.14-00264	Pin	1
23	16.14-00434	Universal joint	1	68	16.14-00104	Bolt	4
24	16.14-00110	Fork	1	69	16.14-00105	O-ring	1
25	16.14-00400	Fork	1	70	16.14-00106	Rubber guard	1
26	16.14-00112	Lock ring	4	71	16.14-00107	Clamp	1
27	16.14-00113	Interm. piece	4	72	24.00-00064	Clamp	1
28	16.14-00112	Lock ring	4	73	16.14-00538	Oil dipstick	1
29	16.14-00114	Cross piece	2	74	16.14-00089	Packing	1
30	16.14-00115	Needle bearing	8		16.14-00539	O-ring	1
31		Ring, outer	8	75		PZ serial number plate	1
32		Needle	232	76	16.14-00466	Rivet	2
33		Seal washer	8	77	16.14-00435	Bearing bolt	1
34	16.14-00268	Protector ring	8	78	16.14-00117	Protector cap	1
35	16.14-00116	Cork ring	8	79	16.14-00467	Catch	1
36	16.14-00401	Screw	1	80	16.14-00468	Screw	1
37	16.14-00402	Washer	1	81	16.14-00119	Screw	1
38	16.14-00334	Clamp ring	1	82	16.14-00428	Emblem	1
39	16.14-00091	Bolt	4	83	16.14-00147	Packing	1
40	16.14-00090	Washer	4	84	16.14-00146	Plug	1
41	16.14-00403	Roller bearing	2				
42	16.14-00404	Bearing sleeve	2				
43	16.14-00405	Shim	A.R.				
	16.14-00406	Shim	A.R.				




## AQ-DRIVE UNIT 270 INTERMEDIATE HOUSING AREA

THE PARTS LISTED BELOW ARE INTERCHANGEABLE WITH VOLVO OUTDRIVES

Code No.	Chris-Craft Part No.	Description	Qty.			
				42	16.14-00339	Astern Complete Lever 1
				43	16.14-00437	Astern Lever 1
1	16.14-00410	Intermediate Housing	1	44	16.14-00438	Bearing Sleeve 1
2	16.14-00129	Gear Yoke	1	45	16.14-00439	Washer, Spacer 1
3	16.14-00338	Astern Lock Rod	1	46	16.14-00440	Rod, Push 1
4	16.14-00130	Shaft	1	47	16.14-00144	Thrust Sleeve 1
5	16.14-00136	Washer	2	48	16.14-00441	Bail, Lock 1
6	16.14-00135	Cotter Pin	2	49	16.14-00442	Pin, Shaft 1
7	16.14-00121	"O" Ring	1	50	16.14-00443	Spring 1
8	16.14-00407	Shim	1	51	16.14-00444	Shaft, Spring 1
	16.14-00408	Shim	1	52	16.14-00445	Washer 1
	16.14-00409	Shim	1	53	16.14-00446	Catch, Spring 1
9	16.14-00342	Fork Complete	1	54	16.14-00447	Shaft 1
10	16.14-00274	Lubricating Nipple	1	55	16.14-00448	Catch, Spring 1
11	16.14-00336	Bushing	1	56	16.14-00449	Nut 1
12	16.14-00139	Needle Bearing	1	57	16.14-00450	Shaft, Stop 1
13	16.14-00140	Seal Ring	2	58	16.14-00451	Spring 1
14	16.14-00340	Steering Plug	2	59	16.14-00452	Spring 1
15	16.14-00123	Bolt Disc.		60	16.14-00453	Nut 1
		Selling 16.14-00086	2	61		Control Cable 1
16	16.14-00337	Nylon Washer	2	62	16.14-00124	Bolt Stud 2
17	16.14-00125	Nut Disc. Selling 16.14-00009	2		16.14-00341	Astern Lever Repair Kit
18	16.14-00131	Control Rod	1			
19	16.14-00132	Fork	1			
20	16.14-00133	Nut	1			
21	16.14-00134	Cotter Pin Bolt	1			
22	16.14-00284	Cotter Pin Disc.				
		Selling 16.14-00135	1			
23	16.14-00385	Guide Sleeve	1			
24	16.14-00141	"O" Ring	1			
25	16.14-00283	Washer	1			
26	16.14-00143	Screw	1			
27	16.14-00142	Screw	2			
28	16.14-00285	Connection Hose Disc.				
		Selling 16.14-00411	1			
29	16.14-00388	Gasket	1			
30	16.14-00145	Bolt	2			
31	16.14-00146	Oil Filler Plug	1			
32	16.14-00147	Gasket	1			
33	16.14-00286	Oil Tube	1			
34	16.14-00122	"O" Ring	2			
35	16.14-00287	Control Cable Connection	1			
36	16.14-00288	Bolt	2			
37	16.14-00291	Washer	2			
38	16.14-00148	Nylon Bearing	2			
39	16.14-00150	Cube	1			
40	16.14-00290	Cotter Pin	1			
41	16.14-00291	Washer	2			






## AQ-DRIVE UNIT 270 LOWER GEAR ASSEMBLY AREA

THE PARTS LISTED BELOW ARE INTERCHANGEABLE WITH VOLVO OUTDRIVES


Code	Chris-Craft						
No.	Part No.	Description	Qty.				
				40	16.14-00420	Shim	3
					16.14-00419	Shim	3
1	16.14-00412	Gear Housing-1.61:1	1		16.14-00418	Shim	3
		Lower Gear Unit	1	41	16.14-00423	Shim	1
		Lower Gear Unit	1	42	16.14-00457	Gasket	1
2	16.14-00413	Gear Housing, Lower	1	43	16.14-00195	"O" Ring	1
3	16.14-00414	Propeller Bearing Housing	1	44	16.14-00196	Spline Sleeve	1
4	16.14-00377	Exhaust Port	1	45	16.14-00188	Lock Ring	1
5	16.14-00155	Bolt	1	46	16.14-00197	Bolt	4
6	16.14-00421	Full Roller Brg.	1	47	04.59-77253	Trimfin Kit	1
8	16.14-00181	Screw	2	48		Allen Screw	1
9	16.14-00368	Intermediate Drive Shaft	1	49	04.59-77243	Cover Plate, Exh. Wye	1
10	16.14-00416	Ball Bearing	1	NOTE: Item 47 and 49 Are Used With Straight Out Exhaust Only.			
11	16.14-00158	Shim	4				
	16.14-00159	Shim	1				
	16.14-00160	Shim	1				
12	16.14-00454	Shaft, Propellor	1				
13	16.14-00162	Needle Bearing	1				
14	16.14-00163	Roller Bearing	1				
15	16.14-00360	Clamp Ring	1				
16	16.14-00164	Lock Washer	1				
17	16.14-00165	Ring Nut	1				
18	16.14-00358	Nut	1				
19	16.14-00455	Lock Washer	1				
20	16.14-00422	Ball Bearing	1				
21	16.14-00169	Lock Washer	1				
22	16.14-00170	Ring Nut	1				
23	16.14-00415	Gear Kit-1.61:1	1				
		Gears Kit	1				
		Gears Kit	1				
24	16.14-00173	Lock Ring	1				
25	16.14-00376	Strainer	1				
26	16.14-00351	Centrifugal Pump	1				
27	16.14-00456	Washer, Thrust	1				
28	16.14-00176	Stud Bolt	6				
29	16.14-00177	Nut	6				
30	16.14-00353	"O" Ring	2				
31	16.14-00347	Zinc Ring	1				
32	16.14-00180	Screw	2				
33	16.14-00182	Seal Ring	2				
34	16.14-00183	Thrust Ring	1				
35	16.14-00184	Propeller Cone	1				
36	16.14-00185	Lock Washer	1				
37	16.14-00186	Plug	1				
38	16.14-00539	Washer Disc.	1				
39	16.14-00420	Shim	3				
	16.14-00419	Shim	AR				
	16.14-00418	Shim	AR				



## AQ-DRIVE UNIT 270 MECHANICAL LIFT


THE PARTS LISTED BELOW ARE INTERCHANGEABLE WITH VOLVO OUTDRIVES

Code Chris-Craft						
No.	Part No.	Description	Qty.			
				40	16.14-00475	Resilient Washer 1
				41	16.14-00476	Screw 1
1	16.14-00198	Mechanical Electric Lift	1	42	16.14-00477	Screw 1
2		Lift Device	1	43	16.14-00478	Lock Nut 2
3	16.14-00199	Lower Part	1	44	16.14-00479	Cable Unit 1
4	16.14-00386	Upper Part	1	45		Cable and Cable Terminals
5	16.14-00382	Screw Spindle	1	46	16.14-00480	Bushing 1
6		Break Nut	1			
7	16.14-00383	Worm Gear Complete	1			
8		Worm Screw	1			
9	16.14-00201	Seal Nut	1			
10	16.14-00202	End Screw	1			
11	16.14-00369	Lock Washer	1			
12	16.14-00293	Spring	1			
13	16.14-00469	Bushing	1			
14	16.14-00294	Key	1			
15	16.14-00470	Guide				
16	16.14-00295	Lock Ring	1			
17	16.14-00296	Ball Bearing	2			
18	16.14-00297	Ball Bearing	1			
19	16.14-00298	Lock Ring	1			
20	16.14-00203	"O" Ring	1			
21	16.14-00204	"O" Ring	1			
22	16.14-00205	Electrical Motor	1			
23	16.14-00206	Relay	1			
24	16.14-00200	Relay	1			
25	16.14-00208	Switch Sell:-16.14-00301	1			
26	16.14-00209	Switch	1			
27	16.14-00355	Bulb	1			
28	16.14-00306	Bulb Holder	1			
29	16.14-00232	Glass	1			
30	16.14-00307	Socket for Warning Lamp	1			
31	16.14-00308	Instrument Plate	1			
32	16.14-00236	Bracket	1			
33	16.14-00237	Protecting Cover	1			
34	16.14-00384	Gasket	1			
35	16.14-00471	Screw	4			
36	16.14-00472	Screw	2			
37	16.14-00473	Nut	2			
38	16.14-00474	Lock Washer	6			
39	16.14-00210	Circuit Breaker	1			





Outboard drive models 280 and 280T



# INSTRUCTION BOOK

## AQUAMATIC

### OUTBOARD DRIVE

#### 280 • 280T

### Contents

<b>Description</b>	2
<b>Running Instructions</b>	Controls . . . . . 4
	Running in shallow water . . . . . 5
	Running in reverse . . . . . 6
	The trim of the boat . . . . . 6
	Adjustment of steering rods in case of twin engine installation . . . . . 7
	Adjusting for deviation from course . . . . . 8
	Trailing . . . . . 8
<b>Periodical Servicing</b>	Maintenance scheme . . . . . 9
	Checking the oil level in outboard drive . . . . . 9
	Checking the oil level in hydraulic tank, 280T . . . . . 10
	Changing the oil in outboard drive . . . . . 10
	Greasing the drive shaft bearing and steering bearings . . 11
	Checking the anti-corrosion devices . . . . . 12
<b>Service Instructions</b>	Removing and fitting the propeller . . . . . 13
	Adjusting the retaining pawl and control cable, 280 . . . . 14
	Connecting up gear control cable, 280 and 280T . . . . . 15
	General inspection . . . . . 15
	Preparing the unit for laying up . . . . . 16
<b>Electrical Wiring Diagrams</b>	Electrical wiring diagrams for drives 280 and 280T . . . . 17
<b>Internal Power Trim</b>	Hydraulic function layout, drive 280T . . . . . 18
<b>Technical Data</b>	19
<b>Altering Direction of Rotation</b>	Adjustment from L-H to R-H propeller . . . . . 20

We reserve the right to make alterations in construction and for this reason the contents of this book is not binding.


## DESCRIPTION

### Drive 280

The Aquamatic outboard drive 280 is a development of the earlier well-known 270 drive. It is flexibly mounted on a collar bolted to the outside of the boat transom and can be tilted up with the help of an electromechanical lifting device.

The lower gear housing on the drive 280 is designed to provide very low current resistance at high speeds.

All exposed parts are made of corrosion-resistant material.






### Drive 280T

Aquamatic outboard drive 280T is equipped with Internal Power Trim, which means that the drive can be hydraulically trimmed in and out from the boat operator's seat for optimum performance, and can also be tilted up.

Drive 280T is otherwise identical with drive 280.




1. Electromechanical device for lifting drive
2. Bellows cover for drive joint
3. Silent Shift cone clutch (patented) ensures reliable and smooth engagement
4. Shift mechanism with power-assisted disengagement for easy shifting
5. Propeller gear with generously dimensioned bevel gear for quiet running and long lifetime
6. Water intakes for engine cooling water
7. Mechanical retaining pawl. In the event of striking against an underwater obstacle, the pawl permits the drive to tilt up. This reduces the risk of damage to the drive. Rapid reverse manoeuvre, e.g. emergency stopping up to 15 knots without drive "floating up"
8. Exhaust bellow for outgoing cooling water and exhaust gases
9. Bellows cover for trim cylinder
10. Trim cylinder for hydraulically adjusting drive to correct trim underway
11. Hydraulic tank with built-in hydraulic pump
12. Lift cylinder for hydraulically lifting drive to "Beach and Tilt" positions. If striking an underwater obstacle a safety valve in hydraulic system opens and the drive is released to tilt up. The risk of damage to drive and propeller is thus reduced. Rapid reverse manoeuvre, e.g. emergency stopping can be carried out up to 15 knots without drive "floating up".
13. Control valve for Forward, Reverse and Neutral
14. Lift yoke, well sealed against impurities and underwater growth

## RUNNING INSTRUCTIONS

### Controls

Described below are the Volvo Penta Single and Twin Control Systems with synchronized throttling and shifting.



Volvo Penta Twin Control System

1. Control lever
  2. Neutral throttle knob
- Push the button when the control lever is in neutral and move the lever forward a bit. Release the button. The gear cannot be engaged. Push in the button again and pull back the lever for synchronized throttling and shifting.

Volvo Penta Single Control System

N = Neutral position  
F = Forward position  
R = Reverse position  
T = Throttle

### LIFTING THE DRIVE

The 280 drive can be lifted and lowered with the help of the electromechanical lift. It is operated by a switch on the control panel. When the warning lamp lights red, this means that the drive is far enough up to disengage the retaining pawl.

**The engine must never be started while the drive is fully up.**


The 280T drive is equipped with Power Trim, with which it is possible to manoeuvre the drive while underway to "Trim" and "Beach". The drive can also be lifted to "Tilt", that is, it is fully up when the engine is stopped.

**The engine must never be started while the drive is at "Tilt".**

The drives Power Trim is manoeuvred by means of the control on the panel. The trim indicator always shows the position of the drive.

**NOTE. The drive may not be manoeuvred while "Reverse" gear is engaged.**

## RUNNING INSTRUCTIONS



### A. Trim

The drive is manoeuvrable while underway for optimum performance.

### B. Beach

The drive is manoeuvrable within "Beach" while underway at low speed and idling, in order to be able to run in shallow water. Once the drive has been adjusted to this position, "Forward" and "Reverse" can be engaged and the speed increased.

### C. Tilt

**The engine must not be started or driven while the drive is within the tilt area.** "Tilt" is intended to be used when the boat is moored in shallow water or when being transported on a trailer.

## Running in shallow water

### DRIVE 280



When running in shallow water at low speed with great risk of contacting the bottom, it is recommended as an extra safety measure that the retaining pawl for the outboard drive is released with the drive lift.<sup>1)</sup> **NOTE. Running "Reverse" cannot be carried out with the retaining pawl released.** Release the retaining pawl as follows:

Move the control switch to the "Up" position until the warning lamp lights up and then keep the switch in this position for another 2–4 seconds. This reduces the risk of damage to the propeller and outboard drive if they come into contact with the bottom.

<sup>1)</sup> Normally the outboard drive clicks up automatically if it strikes an object under water.

## RUNNING INSTRUCTIONS

### DRIVE 280T



If the boat is to be run in shallow water and there is risk of contacting the bottom, the engine speed should be cut back to idling and the drive lifted to "Beach" in order to eliminate possible damage to the propeller. Then the engine speed can be stepped up. "Trim" is marked in green on the trim indicator. "Beach" is white and "Tilt" red on the indicator.

If the drive has been lifted to the borderline between the white and red fields on the trim indicator, the boat speed should be low. **If the drive has been lifted so that the pointer on the trim indicator points to the red field, the engine must not be driven.**

## Running in reverse

### DRIVE 280

Running "Reverse" can only be carried out when this drive is fully down and the retaining pawl has locked the drive in this position. The warning lamp indicating lifted drive must always be off before running in reverse.

### DRIVE 280T

Running "Reverse" can be carried out without hindrance with this drive at "Trim" or "Beach". The drive can be operated fully, and thus the boat can be manoeuvred in "Reverse", with the drive adjusted to "Trim" or "Beach".

## The trim of the boat



Range of use for adjusting pin:  
Drive 280

### DRIVE 280

The angle between the outboard drive and the transom is adjustable on drive 280 by moving the adjusting pin to one of the three alternative holes. Normally the best position for the drive is with the adjusting pin in hole 2.

1. Position to counteract "nose-heavy" tendency
2. Normal position
3. Position to counteract "stern-heavy" tendency

## RUNNING INSTRUCTIONS

### DRIVE 280T

The angle between the 280T drive and transom is infinitely adjustable from the boat operator's seat while underway. The trim indicator shows the trim position on the indicator green field. In order to reach maximum speed more quickly or to counteract "stern-heavy" tendencies, the drive should be trimmed in all the way. This means that the trim indicator pointer should point to the bottom of the green field on the indicator. If the maximum speed hull position is such that the boat has a tendency to be "nose-heavy", the drive should be trimmed out so that pointer moves to "Beach".

In order to reach maximum speed hull position more rapidly and also to improve the boat's running in the case of certain boat types, it may be advisable to fit Volvo Penta trim tabs.




Trim range Drive 280T

### Adjustment of steering rods in case of twin engine installation

For optimum propeller efficiency, it is important to adjust the angle of the drives so that the meeting point between the wash from the two propellers is well behind the boat. The angle between the drives increases with deeper V-bottom. See "A" in adjacent illustration. If the angle is too narrow, this will often result in propeller cavitation.

Fine adjustment of this angle can be carried out by means of the link between the two drive steering rods.



## RUNNING INSTRUCTIONS

### Adjusting for deviation from course



The outboard drive is fitted with a trim tab which can be turned to counteract any tendency towards deviation from course in the steering while underway. Check course deviation with the steering wheel in its neutral position and at cruising speed.

The trim tab is adjusted when necessary by loosening the lock screw and turning the **trailing edge** of the trim **towards** the course deviation. Tighten the lock screw and test-run the boat. Repeat adjustment if necessary until the best courseholding is obtained with the steering wheel in the neutral position.

### Trailing



When the boat is being towed on a trailer, the outboard drive should be raised as far as it will go. In order to prevent the drive from shaking down from its tipped-up position, the drive is supplied with a transport bracket, which is fitted as follows:

Place the bracket handle in the yoke recess, press together the lower part of the bracket so that both the pins can be located in the mounting collar holes.

## Maintenance scheme

The servicing procedure in the maintenance scheme below are numbered and these numbers refer to the description on the following pages.

Point	Operation	To be carried out:		
		Every 14 days	After <sup>1)</sup> 50 hours running	After <sup>1)</sup> 100 hours running
	<b>PERIODICAL SERVICING</b>			
1	Checking the oil level in outboard drive	●		
2	Checking the oil level in hydraulic tank (280T)	●		
3	Changing the oil in outboard drive			●
4	Greasing the drive shaft bearing and steering bearings		●	
5	Checking the anti-corrosion devices	●		
	<b>GENERAL SERVICING INSTRUCTIONS</b>	To be carried out according to the intervals given under the respective points or when necessary		
6	Removing and fitting the propeller			
7	Adjusting the retaining pawl and connecting up the gear control cable, drive 280			
8	Connecting up gear control cable, drive 280T			
9	Carry out general inspections			
10	Preparing the unit for laying up			


1) Or once each season, whichever occurs first

### 1 Checking the oil level in outboard drive

**Check the oil level every 14 days** by using the dipstick in the cover over the upper gear housing. This check must be carried out while the outboard drive is in its lowered position.

The oil dipstick should not be screwed in when the oil level is checked.

The oil level should be within the field on the lower flat part of the dipstick.



## PERIODICAL SERVICING



The correct oil grade and viscosity are shown in the "Technical Data". Fill up through the dipstick hole or through the oil filler hole just inside the protective cover after the drive has been tilted up.

## 2 Checking the oil level in hydraulic tank, drive 280T



Hydraulic tank

1. Oil dipstick
2. Oil filler hole

**Check the oil level in the hydraulic tank every 14 days** by using the dipstick on top of the tank. Observe great care when carrying out this check that no foreign particles drop down into the tank.

The oil level should be within the field on the flat part of the dipstick.

When necessary top up through the oil filler hole to the correct level with oil which meets the requirements given in "Technical Data". NOTE Ordinary engine oil must not be used.

## 3 Changing the oil in outboard drive

Changing the lubricating oil after every 100 hours running or at least once each season. Tilt up the drive and drain off the old oil by removing the plug. The oil filler plug should be unscrewed to enable the oil to run out more easily.



## PERIODICAL SERVICING

Fill up with oil through the oil filler hole. Concerning quality and viscosity, see "Technical Data". The drive should be in its tilted-up position when oil is being filled.

After filling up, screw the oil filler plug into position again and lower the drive completely. Check the oil level by following the instructions in point 1 and fill up if required through the dipstick hole or oil filler hole. Make sure that the O-rings under the plugs and dipstick are in good condition.

**NOTE.** Never allow the oil level to get above the MAX mark on the dipstick.



Oil draining



Oil filling

### 4 Greasing the drive shaft bearing and steering bearings

After every 50 hours running the lubricating points mentioned below must be greased with Multipurpose grease:

The drive shaft bearing in the flywheel housing is greased by filling the grease nipple with grease and screwing it in all the way.

The steering rod bearing is greased through the lubricator on the inside of the mounting collar. Force in so much grease that it seeps out at the bearing.



## PERIODICAL SERVICING



The steering shaft bearing is greased through the grease nipple by using a grease gun. Force in so much grease that it seeps out at the wear washer.

## 5 Checking the anti-corrosion devices

At least every 14 days check how much the zinc electrodes have been corroded. When about 50 % of the original size has been corroded away, replace the electrodes as follows:



### ZINC RING

Remove the propeller and spacer ring with deflector ring (see point 6 "Removing and fitting the propeller") and remove the Philips screws retaining the zinc ring.

Scrape the contact surface against the bearing housing clean and fit a new zinc ring. Make sure that there is good metallic contact between the zinc ring and the propeller housing.

### ZINC PLATE

Unscrew the zinc plate which is fitted under the mounting collar. Clean the contact surfaces and fit a new zinc plate. **NOTE.** The drive 280T has two zinc plates, one on each side of the trim cylinder.

**NOTE.** Do not paint the zinc ring or zinc plate.



## 6 Removing and fitting the propeller

1. Knock up the tabs on the lock washer for the propeller cone.
2. Unscrew the propeller cone with the help of a screwdriver which is pushed in through the hole in the propeller cone. Then pull off the propeller. Note the spacer ring on the inside of the propeller.
3. Clean the propeller shaft and apply graphite grease, or equivalent, to the shaft.
4. **When changing the propeller, check that the new one has the same size and markings as the earlier unit.**
5. Fit the propeller. **NOTE.** The spacer ring and deflector ring (see Fig) should be fitted between the propeller and the gear housing.




**NOTE.** Lock the propeller cone by staking all the teeth on the lock washer.

If the teeth of the lock washer do not fit in the middle of the cone recess, unscrew the cone and move the lock washer one spline position on the propeller shaft.

## SERVICE INSTRUCTIONS

### 7 Adjusting the retaining pawl and connecting up the gear control cable, drive 280

Check once each season, and adjust when necessary, the position of the locking rod against the retaining pawl "A" and also the position of the push rod "B" for lift disengagement of the retaining pawl. Adjust as follows:



Adjusting retaining pawl,  
drive 280.

1. Remove the protective cover (12) on the upper gear housing in order to get at the shift mechanism. Move the control lever to the neutral position.
2. Disconnect the gear control cable "dice" (9) from the lever (8) and the yoke (11) from the gear lever.
3. Loosen the locknut for the yoke (11) and turn the yoke on the gear rod (10) thread so that at the connection with the gear lever the push rod (6) goes into such a position that it just contacts (without pressure) the pawl at "A". Secure the yoke (11) in this position with the locknut.
4. Adjust the gear cable "dice" (9) so that it can easily be moved into the hole on the lever (8) and secure it in this position. Move the control lever to the "Forward" position and check that the corner "C" does not contact the intermediate housing. Fit the cover over the gear shift mechanism.
5. **Press the drive forward, against the adjusting pin,** and check the position of the push rod (3). The upper part (2) of the rod should be level with the yoke (at

### **8 Connecting up gear control cable, drives 280 and 280T**

In those cases where the drive has been removed from the boat and is to be re-fitted, the gear control cable must be connected to the drive shift mechanism as follows:

1. Move the control lever at the boat operator's seat to neutral position.
2. Remove the protective cover over the shift mechanism. Move the shift mechanism lever to neutral position.
3. Push the gear control cable in as far as it can go and then pull it out fully in order to check for play. Then push in the cable to half the length of the measured play. Screw on the "dice" so far that its pin fits in the lever on the shift yoke. Lock the "dice" with the locknut on the gear control cable.
4. Check that the "dice" and the gear rod are properly adjusted by moving the control lever to "Forward", "Neutral" and "Reverse" while checking at the same time that the "dice" and gear rod do not jam in their bearings. Adjust if necessary.

Check to make sure that the corner "C" (point 7) does not knock against the housing.

5. Lock the "dice" to the lever with washer and split pin.

### **9 Carry out general inspection**

General inspection of the outboard drive must be carried out after every 100 hours running or at least once each season. Clean the outside of the drive and touch up any damaged paintwork. Paint the underwater parts of the drive and also the cooling water intake channels with anti-fouling paint (must not include copper or mercury).

**NOTE. Do not paint the zinc ring or zinc plate.**

At the same time check for oil leakage and ensure that the rubber bellows are in good condition and that there is no abnormal wear on the links for the control mechanism.

For drive 280T, the Internal Power Trim should also be checked to make sure that there is no leakage at connections or joints.

## SERVICE INSTRUCTIONS

### 10 Preparing the unit for laying up

Even insignificant corrosion on precision-machined parts can result in a serious deterioration in the condition of these parts.

If the outboard drive is to remain idle for a longer period than one month, we recommend that it should be given protective treatment as described below.

#### PROTECTIVE TREATMENT

Drain off the oil from the drive and fill up with preservative oil (for example, Shell Ensis Oil 20 or similar). **NOTE.** The hydraulic system on drive 280T does not require protective treatment. First clean the drive externally with fresh water and then with kerosene or similar solvent. Remove all marine growth and deposits. Then touch up any of the paintwork that may be damaged. **NOTE. Do not paint the zinc ring and zinc plate.** Protect the outboard drive externally by applying rust-proofing oil.

If the outboard drive is dismantled from the boat, a cover has to be fitted over the stub shaft in the flywheel housing.


#### PREPARING FOR USE AGAIN

Drain off the preservative oil from the outboard drive. Fill up with oil (see "Servicing", point 3).

Clean the outboard drive externally from rust-proofing oil and replace the zinc ring and zinc plate on the outboard drive, see "Servicing", point 5.

Carefully check the bellows for damage and re-tighten all hose clips. If the drive has been removed, make sure when re-fitting that the bellows and noses are correctly fitted. Adjust the control cable and retaining pawl, see "Servicing", point 7 for drive 280 and point 8 for drives 280 and 280T.

Paint the underwater parts of the outboard drive and the cooling water intake channels with anti-fouling paint (must not include copper or mercury).




Painting the outboard drive

1. Drive
2. Primer
3. Surface coat
4. Anti-fouling coat


# Electrical wiring diagrams

Drive 280



1. Relay box
2. Relay
3. End position switch
4. Push rod, retaining pawl
5. Connector
6. Electric motor
7. Manoeuvre switch
8. Warning lamp
9. Key switch
10. Connected to 30 (+) on starter motor


Drive 280T



11. Connected engine body
12. Sender for trim indicator
13. Trim indicator
14. Switch, instrument panel lighting
15. Temperatur gauge
16. Instrument panel, trim
17. Main instrument panel

# Internal Power Trim, 280T

## Hydraulic function layout



Hydraulic function for Internal Power Trim, outboard drive 280T

- |                             |  |
|-----------------------------|--|
| 1. Motor                    | 15. Lift cylinder                        |
| 2. Tank                     | 16. Safety valve                         |
| 3. Relief valve, lifting    | 17. Piston, lift cylinder                |
| 4. Return tank              | 18. Lift yoke                            |
| 5. Check valve for lifting  | 19. Control valve, closes when reversing |
| 6. Drain tank, filtered oil | 20. Control lever                        |
| 7. Pump                     | 21. Hose                                 |
| 8. Check valve for lowering | 22. Contact face, trim cylinder – drive  |
| 9. Strainer                 | 23. Rubber bellow                        |
| 10. Relief valve, lowering  | 24. Piston, trim cylinder                |
| 11. "Beach" valve           | 25. Trim cylinder                        |
| 12. Hose                    | 26. Hose                                 |
| 13. Venting nipple          | 27. Ball valve                           |
| 14. Safety release valve    | 28. Ball valve                           |



# Technical Data

Type designations	
Drive with electromechanical lift device	Aquamatic 280
Drive with Internal Power Trim	Aquamatic 280T
Reduction ratios, total, "Forward" and "Reverse"	1.61:1/280 B 1.89:1/280 C 2.15:1/280 D
Shift mechanism	"Silent Shift" self-adjusting cone
Maximum propeller diameter	16"
Tip-up angle, drive 280	0°–60°
Tip-up angle, drive 280T	
Trim position	–4°–+5°
Beach position	5°–30°
Tilt position	30°–60°
Lift unit, type	
drive 280	Electromechanical
drive 280T	Hydraulic
Lubricating system	Circulation pump for oil supply to all lubricating points
Oil capacity, outboard drive, approx.	2 1/2 US qts. (2.6 liters)
Oil capacity between max. and min. marks, approx.	1/5 pint (0.15 liter)
Oil quality	Multigrade Service SE1)
Oil viscosity	SAE 10W/30 or 20W/40
Oil capacity, hydraulic system, drive 280T, approx.	1 1/2 US qts. (1.5 liters)
Oil quality, hydraulic system, drive 280T	Automatic Transmission Fluid, Type F, A2) or Dexron 2)

1) Earlier designation, Service MS


2) Only if type F is not available

## Adjustment for change from L-H to R-H propeller

The gears in the outboard drive are designed to operate in either direction of rotation, for use with either left-hand or right-hand propeller.

In the standard unit, for use with left-hand propeller, the lower clutch-and-gear functions as the forward drive gear. If it is desired to use a right-hand propeller, as required for the starboard unit of a pair, the linkage of the shifting mechanism may be reversed by a simple change in the assembly, whereupon the upper gear will become the forward drive gear. The procedure then is as follows:

1. Remove the cover from the gear mechanism.
2. Move the gear control rod from "A" to "B", see Figure.




By reference to the Fig. it will be observed that in both positions of the gear rod (A and B), the cable from the shift control lever has a "push" motion for engaging the forward gear. Check and adjust the shift linkage according to "Servicing", point 7, page 14.

## AQ-DRIVE UNIT 280 CONNECTING COMPONENTS

THE PARTS LISTED BELOW ARE INTERCHANGEABLE WITH VOLVO OUTDRIVES

Code No.	Chris-Craft Part No.	Description	Qty.				
				47	16.14-00020	Nut	2
				48	16.14-00019	O-ring	1
				49	16.14-00151	Rubber hose	1
1	16.14-00405	Shield	1	50	16.14-00510	Hose clamp	2
2	16.14-00406	Steering yoke	1	51	16.14-00511	Hose with rubber bellows	1
3	16.14-00321	Grease nipple	1	52	16.14-00512	Clamp	1
4	16.14-00407	V-ring	1	53		Control cable	1
5		Bushing	2	54	16.14-00034	Packing	1
6	16.14-00001	Stud	2	55	16.14-00252	Screw	6
7	16.14-00024	Bearing ball	2	56	16.14-00035	Packing	6
8	16.14-00023	Washer	2	57	16.14-00253	Washer	6
9	16.14-00322	Nut	2	58	16.14-00254	Nut	6
10	16.14-00488	Bushing, lower	1	59	16.14-00513	Primary shaft	1
11	16.14-00489	Bushing, upper	1	60	16.14-00514	Ball bearing	1
12	16.14-00319	Protecting cap	1	61	16.14-00067	Circlip	1
13		Bushing	1	62	16.14-00065	Circlip	3
14	16.14-00490	Emblem "Volvo Penta"	1	63	16.14-00515	Seal-ring	1
15	16.14-00491	Drive screw	2	64	16.14-00034	Ball bearing	1
16	16.14-00241	Allen screw	2	65	16.14-00515	Seal ring	1
17	16.14-00002	Rubber seal	1	66	16.14-00517	Primary shaft housing	1
18	16.14-00492	Screw	4	67	16.14-00186	Plug	1
19	16.14-00006	O-ring	1	68	16.14-00518	Washer	6
20	16.14-00493	Exhaust outlet	1	69	16.14-00519	Nut	6
21	16.14-00028	Exhaust bellow	1	70	16.14-00522	Rubber hose	1
22	16.14-00494	Ring	9	71	16.14-00521	Hose clamp	2
23	16.14-00029	Hose clamp	3	72	16.14-00522	Rubber hose	1
24	16.14-00356	Rubber bend	1	73	16.14-00521	Hose clamp	2
25	16.14-00363	Washer	1	74		Cables and cable terminals	1
26	16.14-00366	Plug	1	75	16.14-00524	Hose union	1
27	16.14-00034	Packing	1	76	16.14-00525	Elbow union	1
28	16.14-00370	Zink electrode	1	77	16.14-00526	Rubber hose	1
29	16.14-00371	Allen screw	2	78	16.14-00521	Hose clamp	2
30	16.14-00008	Setting pin	1	79	16.14-00380	Catch	1
31	16.14-00009	Nut	2	80	16.14-00528	Protection cap	1
32	16.14-00010	Bearing pin	2	81	16.14-00529	O-ring	4
33	16.14-00011	Allen screw	2	82	16.14-00530	Washer	2
34	16.14-00012	Washer	2	83	16.14-00531	Restriction	1
35	16.14-00013	Clamping ring kit	1				
36	16.14-00014	Rubber ring	2				
37	16.14-00015	Screw	6				
38	16.14-00016	Lock washer	3				
39	16.14-00495	Rubber cushion	1				
40	16.14-00459	Packing	2				
41	16.14-00460	Washer	2				
42	16.14-00461	Nut	2				
43	16.14-00509	Steering lever	1				
44	16.14-00589	Screw	1				
45	16.14-00375	Washer	1				
46	16.14-00379	Water pipe grommet	1				




## AQUAMATIC-DRIVE UNIT 280

THE PARTS LISTED BELOW ARE INTERCHANGEABLE WITH VOLVO OUTDRIVES

Code	Chris-Craft					
No.	Part No.	Description	Qty.			
				3	16.14-00410	Interm. housing
				4	16.14-00545	Lower gear unit
1	48.71-00023	AQ-drive unit 280B	1		16.14-00499	Gasket set
2	16.14-00500	Upper gear unit	1			


①



## AQ-DRIVE UNIT 280 UPPER GEAR UNIT

THE PARTS LISTED BELOW ARE INTERCHANGEABLE WITH VOLVO OUTDRIVES

Code	Chris-Craft						
No.	Part No.	Description	Qty.		16.14-00532	Shim	A.R.
1	16.14-00500	Upper gear unit	1	44	16.14-00406	Shim	A.R.
2	16.14-00391	Housing	1		16.14-00407	Shim	A.R.
3	16.14-00464	Stud	2		16.14-00408	Shim	A.R.
4	16.14-00392	Cover	1	45	16.14-00409	Shim	A.R.
5	16.14-00146	Plug	1	46	16.14-00078	Shaft	1
6	16.14-00147	Packing	1	47	16.14-00325	Sliding sleeve	1
7	16.14-00123	Bolt	3	48	16.14-00081	Spring	1
8	16.14-00431	Hollow screw	1	48	16.14-00082	Washer	1
9	16.14-00393	O-ring	1	49	16.14-00533	Lock ring	1
10	16.14-00394	Gasket	1	50	16.14-00077	Needle bearing	4
11	16.14-00501	Gear set	1	51	16.14-00262	Spacer ring	2
12	16.14-00328	Double bearing unit	1	52	16.14-00263	Spacer ring	1
13	16.14-00465	Peg	1	53	16.14-00083	Lock ring half	2
14	16.14-00502	Roller bearing	1	54		Nut	1
15	16.14-00503	Roller bearing	1		16.14-00534	Nut with wear plate	
16	16.14-00062	O-ring	2		16.14-00535	Nut with wear plate	
17	16.14-00063	Shim	A.R.	55	16.14-00536	Nut with wear plate	
	16.14-00064	Shim	A.R.	56	16.14-00326	Gear mechanism	1
18	16.14-00504	Seal ring	1	57	16.14-00093	Bearing housing	1
19	16.14-00433	Lock ring	1	58	16.14-00094	Eccentric piston	1
20	16.14-00396	Head washer	1	59	16.14-00327	Sliding shoe	1
21	16.14-00066	O-ring	1	60	16.14-00097	Steel ball	1
22	16.14-00397	Shim	A.R.	61	16.14-00102	Steel ball	2
	16.14-00398	Shim	A.R.	62	16.14-00537	Spring	2
	16.14-00399	Shim	A.R.	63	16.14-00095	Lock wire	A.R.
23	16.14-00482	Universal joint	1	64	16.14-00096	Bolt	1
24	16.14-00110	Fork	1	65	16.14-00099	Shim	A.R.
25	16.14-00506	Fork	1	66	16.14-00103	Seal ring	1
26	16.14-00112	Lock ring	4	67	16.14-00101	Lock pin	1
27	16.14-00113	Interm. piece	1	68	16.14-00204	Pin	1
28	16.14-00267	Lock ring	4	69	16.14-00104	Bolt	4
29	16.14-00114	Cross piece	2	70	16.14-00105	O-ring	1
30	16.14-00115	Needle bearing	8	71	16.14-00106	Rubber guard	1
31		Ring outer	8	72	16.14-00107	Clamp	1
32		Needle	232	73	24.00-00064	Clamp	1
33		Seal washer	8	74	16.14-00538	Oil dipstick	1
34	16.14-00268	Protector ring	8	75	16.14-00539	Packing	1
35	16.14-00116	Cork ring	8	76	16.14-00330	PZ-serial number plate	2
36	16.14-00507	Screw	1	77	16.14-00540	Rivet	2
37	16.14-00508	Washer	1	78	16.14-00435	Bearing bolt	1
38	16.14-00334	Clampring	1	79	16.14-00117	Protector cap	1
39	16.14-00091	Bolt	4	80	16.14-00541	Catch	1
40	16.14-00090	Washer	4	81	16.14-00342	Screw	1
41	16.14-00590	Roller bearing	2	82	16.14-00119	Screw	1
42	16.14-00404	Bearing sleeve	2		16.14-00543	Emblem	1
43	16.14-00405	Shim	A.R.				






## AQ-DRIVE UNIT 280 INTERMEDIATE HOUSING

THE PARTS LISTED BELOW ARE INTERCHANGEABLE WITH VOLVO OUTDRIVES


Code No.	Chris-Craft Part No.	Description	Qty.				
				45	16.14-00441	Lock ball	1
				46	16.14-00442	Shaft pin	2
				47	16.14-00443	Spring	1
1	16.14-00410	Interm. housing	1	48	16.14-00444	Springshaft	1
2	16.14-00129	Gear yoke	1	49	16.14-00445	Washer	1
3	16.14-00338	Astern lock rod	1	50	16.14-00446	Spring catch	1
4	16.14-00130	Shaft	1	51	16.14-00447	Shaft	1
5	16.14-00138	Washer	2	52	16.14-00448	Spring catch	1
6	16.14-00135	Cotter pin	1	53	16.14-00449	Nut	2
7	16.14-00121	O-ring	1	54	16.14-00450	Stop shaft	1
8	16.14-00407	Shim	A.R.	55	16.14-00451	Spring	1
	16.14-00408	Shim	A.R.	56	16.14-00452	Spring	2
	16.14-00409	Shim	A.R.	57	16.14-00453	Nut	1
9	16.14-00342	Fork	1	58	16.14-00124	Stud	2
10	16.14-00274	Lubr. nipple	1	59		Control cable	A.R.
11	16.14-00336	Bushing	1	60	16.14-00341	Repair kit, astern lever	1
12	16.14-00139	Needle bearing	1				
13	16.14-00140	Seal	2				
14	16.14-00123	Bolt	2				
15	16.14-00337	Washer	2				
16	16.14-00125	Nutter	2				
17	16.14-00131	Control nut	1				
18	16.14-00132	Fork	1				
19	16.14-00133	Nut	1				
20	16.14-00134	Cotter pin bolt	1				
21	16.14-00135	Cotter pin	2				
22	16.14-00585	Guide sleeve	1				
23	16.14-00141	O-ring	1				
24	16.14-00283	Washer	1				
25	16.14-00143	Bolt	1				
26	16.14-00142	Bolt	2				
27	16.14-00544	Hose union	1				
28	16.14-00388	Gasket	1				
29	16.14-00145	Bolt	2				
30	16.14-00200	Oil tube	1				
31	16.14-00122	O-ring	2				
32	16.14-00287	Cable connection	1				
33	16.14-00288	Bolt	2				
34	16.14-00291	Washer	2				
35	16.14-00148	Bushing	3				
36	16.14-00150	Cube	1				
37	16.14-00290	Cotterpin	1				
38	16.14-00291	Washer	2				
39	16.14-00339	Astern lever kit	1				
40	16.14-00437	Astern lever	2				
41	16.14-00438	Bearing sleeve	1				
42	16.14-00439	Spacer washer	2				
43	16.14-00440	Push rod	1				
44	16.14-00144	Push sleeve	1				



## AQ-DRIVE UNIT 280 LOWER GEAR UNIT

THE PARTS LISTED BELOW ARE INTERCHANGEABLE WITH VOLVO OUTDRIVES


Code No.	Chris-Craft Part No.	Description	Qty.			
				42	16.14-00185	Lock washer 1
				43	16.14-00184	Propeller cone 1
1	16.14-00545	Lower gear unit	1	44	16.14-00555	Plug 1
2	16.14-00547	Bearing housing	1	45	16.14-00556	Packing 1
3	16.14-00546	Gear housing	1	46	16.14-00195	O-ring 1
4	16.14-00548	Steering fin	1	47	16.14-00196	Spline sleeve 1
5	16.14-00549	Bolt	1	48	16.14-00188	Lock ring 1
6	16.14-00421	Needle bearing	1	49	16.14-00197	Bolt 4
7	16.14-00181	Screw	2			
8	16.14-00550	Exhaust port	1			
9		Rubber lip	1			
10		Plate	1			
11		Rivet	6			
12	16.14-00368	Shaft	1			
13	16.14-00416	Ball bearing	1			
14	16.14-00158	Shim	A.R.			
	16.14-00159	Shim	A.R.			
	16.14-00160	Shim	A.R.			
15	16.14-00457	Gasket	1			
16	16.14-00551	Shim	A.R.			
17	16.14-00163	Roller bearing	1			
18	16.14-00420	Shim	A.R.			
	16.14-00419	Shim	A.R.			
	16.14-00418	Shim	A.R.			
19	16.14-00360	Clamp ring	1			
20	16.14-00164	Lockwasher	1			
21	16.14-00165	Ring nut	1			
22	16.14-00376	Strainer	1			
23	16.14-00552	Propeller shaft	1			
24	16.14-00162	Needle bearing	1			
25	16.14-00415	Gears kit	1			
26	16.14-00455	Lock washer	1			
27	16.14-00358	Nut	1			
28	16.14-00351	Centrifugal pump	1			
29	16.14-00173	Lock ring	1			
30	16.14-00456	Thrust washer	1			
31	16.14-00176	Stud	6			
32	16.14-00177	Nut	6			
33	16.14-00422	Ballbearing	1			
34	16.14-00423	Shim	A.R.			
	16.14-00424	Shim	A.R.			
35	16.14-00169	Lock washer	1			
36	16.14-00170	Ring nut	1			
37	16.14-00182	Seal ring	2			
38	16.14-00353	O-ring	2			
39	16.14-00553	Zincring	1			
40	16.14-00143	Screw	2			
41	16.14-00554	Thrust ring	1			



## AQ-DRIVE UNIT 280 MECHANICAL LIFT DEVICE

THE PARTS LISTED BELOW ARE INTERCHANGEABLE WITH VOLVO OUTDRIVES


Code	Chris-Craft				
No.	Part No.	Description	Qty.		
				40	16.14-00575 Cable unit
				41	16.14-00578 Cable unit
				42	16.14-00577 Instrument panel
1	16.14-00557	Mek. lift device	1		
2	16.14-00558	Liftdevice	1		
3	16.14-00199	Lower part	1		
4	16.14-00559	Upper part	1		
5	16.14-00382	Screw spindle set	1		
6		Brake nut	1		
7	16.14-00383	Worm screw set	1		
8		Worm screw	1		
9	16.14-00301	Seal nut	1		
10	16.14-00202	Thrust plate	1		
11	16.14-00369	Lock washer	1		
12	16.14-00203	O-ring	1		
13	16.14-00204	O-ring	1		
14	16.14-00296	Ball bearing	2		
15	16.14-00247	Ball bearing	1		
16	16.14-00295	Lock ring	1		
17	16.14-00469	Bushing	1		
18	16.14-00470	Guide	1		
19	16.14-00298	Lock ring	1		
20	16.14-00294	Key	1		
21	16.14-00293	Spring	1		
22	16.14-00561	El. motor	1		
23	16.14-00562	Nut	2		
24	16.14-00478	Nut	2		
25	16.14-00384	Packing	1		
26	16.14-00480	Bushing	1		
27	16.14-00563	O-ring	1		
28	16.14-00564	Screw	2		
29	16.14-00565	Nut	2		
30	16.14-00566	Clamping band	1		
31	16.14-00567	Cover	1		
32	16.14-00568	O-ring	1		
33	16.14-00569	O-ring	2		
34	16.14-00570	Housing	1		
35	16.14-00571	Relay	1		
36	16.14-00572	Relay	1		
37	16.14-00209	Switch	1		
38	16.14-00573	Screw	3		
39	16.14-00574	Cable unit	1		



## INSTRUMENT PANEL MECHANICAL LIFT DEVICE

THE PARTS LISTED BELOW ARE INTERCHANGEABLE WITH VOLVO OUTDRIVES

Code		Chris-Craft					
No.	Part No.	Description	Qty.				
				6	16.14-00307	Housing	1
				7	16.14-00306	Bulb housing	1
1	16.14-00577	Instrument panel	1	8	16.14-00355	Bulb	1
2		Panel	1	9		Screw	
3		Plug	1	10		Cable unit	1
4	16.14-00301	Switch	1	11	16.14-00560	Clamping band	1
5		Glass	1	12		Extension cable	1







## EXTENSION SET

THE PARTS LISTED BELOW ARE INTERCHANGEABLE WITH VOLVO OUTDRIVES

Code	Chris-Craft						
No.	Part No.	Description	Qty.				
				10	16.14-00011	Screw	1
				11	16.14-00582	Screw	2
1	16.14-00579	Extension set	A.R.	12	16.14-00583	Stud	4
2	16.14-00378	Extension set	A.R.	13	16.14-00584	Nut	4
3		Adapter	A.R.	14	16.14-00143	Screw	3
4		Adapter	A.R.	15	16.14-00197	Screw	4
5	16.14-00580	Splines sleeve	A.R.	16	16.14-00141	O-ring	1
6	16.14-00188	Lock ring	A.R.	17	16.14-00122	O-ring	1
7	16.14-00196	Splines sleeve	1	18	16.14-00006	O-ring	1
8	16.14-00188	Lock ring	1	19	16.14-00585	Oilpipe	1
9	16.14-00581	Shaft	1				





# EMERGENCY REPAIRS

## TABLE OF CONTENTS

Introduction .....	130
Trouble Shooting .....	130
Emergency Repairs .....	131
Stay Afloat .....	132
Recommended Basic Tools and Parts .....	132

# EMERGENCY REPAIRS

## introduction

As a boat owner or operator, you may be in a serious situation if your engine fails, or some other emergency trouble develops while at sea and you are unsure of what to do or how to make repairs.

You need not be a mechanic to perform the repairs and do the inspections illustrated in this book. Follow the hints one at a time in order, and always reset adjustments before going on to the next item. Use your head, proceed calmly and methodically. The results of your work may save your boat or your life and will be gratifying when you get underway "ON YOUR OWN."

The illustrations in this booklet are to acquaint you with basic principles and may not be exactly the same as the equipment on your own craft, however, principles remain the same regardless of manufacturer or installation.

## trouble shooting

### STARTING MOTOR WILL NOT OPERATE

**1. Discharged or Low Battery.**—Turn OFF all electrical equipment and wait for about 30 minutes for the battery to recover. While waiting for the recovery, check the cable connections at the battery terminals. Don't just look—remove the clamps and clean the posts, then reclamp.

**2. Defective Starter Switch.**—First inspect the connections for tightness, broken wires or bare wire touching engine frame. To use the test lamp (recommended in tool kit) place one test lead to the ground post of battery (the one bolted to the engine frame or block) and the other test lead to the primary terminal (small wire) on the distributor. When the engine is cranked over, either by hand or starter, the light will light when the distributor points are open if the ignition switch is in the "ON" position and working properly.

### STARTING MOTOR OPERATES BUT WILL NOT ENGAGE

Loosen the starting motor from the engine by removing the attaching bolts. Check the small pinion gear or so-called bendix to see if it is stuck on

the shaft. If it is stuck, free it up with a hammer and oil it with a few drops of oil from the engine dipstick.

**WARNING:** Before attempting any electrical repairs as outlined, make sure bilges and engine compartment are free of explosive vapors.

### STARTING MOTOR OPERATES BUT ENGINE WILL NOT START

**1. Engine Primary Electrical Circuit (Small Wires).**—Look for corroded, dirty, damaged or loose connections in the ignition primary circuits. This includes the wires from the junction box to the ignition switch, the wire to the coil and to the distributor.

**2. Engine Secondary Circuit (Large Wires to Plugs).**—Look for broken or damaged wires to spark plugs and from the coil to the distributor cap. There may be moisture on the wires or on the spark plugs that will cause the spark to be grounded.

**3. Ignition.**—Check the distributor points to see if they are opening and closing as the engine is cranked. Stop the cranking with the points in their maximum open position. The opening should be about .020 inches. NOTE: A matchbook cover may be used in an emergency to measure this point gap.

Inspect the distributor cap to see if the contact button is in place and is free to move. This contact is to carry current from the coil to the spark plug wires and must make contact with the rotor.

**IMPORTANT:** Don't forget to replace the rotor after you inspect the distributor.

**4. Quick Spark Test.**—A firing indicator (pencil type) is a fast effective way to check spark plug and ignition cable voltage. To check spark plug, touch the end of the indicator to the cable boot. To check cable, slide grooved swivel end over length of the cable. As fire passes through wire, window of firing indicator will light. A firing indicator can be purchased at most parts stores. Champion Spark Plug Division has an indicator under their part no. CT-438.

**WARNING:** Before attempting any electrical repairs as outlined make sure bilges and engine compartment are free of explosive vapors.

### STARTING MOTOR OPERATES, SPARK IS GOOD BUT ENGINE WILL NOT START

**1. Out of Fuel?**—Tank empty? Always check fuel before leaving port. Good rule to follow is never cruise farther than one third of your fuel supply.

Save two thirds for the return trip.

**2. Is Fuel Reaching the Fuel Pump?**—See if the fuel filter or sediment bowl is filled with fuel. If it is not, and if the tank is full then the shut off cock may have vibrated closed or a fuel line may be clogged. Disconnect the inlet side of the pump and blow through the line. Look for dents in the fuel line and air leaks in the fuel pump gaskets or in the fuel line connections. Make sure the gasoline tank vent is open.

**3. Is Fuel Reaching the Carburetor?**—Remove the sediment bowl from the fuel pump and see if the screen in the pump body is clean. Then disconnect the outlet line from the fuel pump to the carburetor and see if fuel flows out when the engine is cranked. Make sure ignition is OFF when making this test. Pulling out the coil wire will insure that the ignition is dead.

**4. Is Fuel Reaching the Cylinders?**—Remove the spark plugs and see if they are moist. If there is no fuel on the plugs, the carburetor may be out of adjustment. Many marine carburetors have a main jet adjustment that can be turned to increase the fuel flow.

**5. Is the Choke Closing Properly?**—This is especially important on dual carburetors if the linkage permits one choke to remain open, both chokes will be out of service.

**6. Engine May Be Flooded.**—If the spark plugs are wet, this indicates flooding caused by using the choke too long. The correct way to dry out the cylinders is to OPEN the throttle wide. Put the choke in the open position (NON-CHOKING), and with the ignition ON crank the engine several times. This draws nothing but air through the carburetor, NOTE: Always replace the flame arrester before cranking the engine.

#### ENGINE OVERHEATS

1. Check to see that the surge tank cap seats in the filler neck and releases at specified pressure.

2. Check coolant level.

3. Check temperature sending unit and/or gauge.

4. Check engine thermostat.

5. Check water pump belts for excessive looseness.

6. Check for punctures in heat exchanger; ruptured or disconnected hoses, loose pressure cap or use of low boiling point antifreeze. These conditions prevent cooling system from maintaining proper pressure.

7. Clean debris from heat exchanger (sea water tubes)

8. Check engine operation to make sure tune-up

is not needed. Improper timing may cause overheating.

9. Check for plugged or damaged strainer or thru hull fitting.

10. Check for collapsed or deteriorated suction hose from thru hull fitting or strainer to sea water pump.

11. Check sea water pump for excessive wear, damaged impeller, or obstruction in pump intake.

12. Check reverse gear oil cooler for foreign matter that might restrict water flow.

13. Check pressure relief valve and heat exchanger for foreign matter that might restrict water flow.

14. Check for plugged exhaust or excessive exhaust back pressure.

15. Check circulating water pump for defective impeller or impeller loose on shaft.

## emergency repairs

Most emergency repairs can be made with what you have on board. With a little imagination you can make most anything needed to get underway. Let's take a look at what people have done in the past.

**Broken Fan Belt.**—Fan belts are made to last for a long time; however, it's a good idea to carry a spare for emergencies. A replacement can also be made from a piece of line or rope. Simply tie the line around the pulleys, securing the ends with a splice or square knot. Tighten the movable pulley and you're underway again.

**Broken Pipe or Hose.**—Use FIRST AID. Bandage the break with rags or a piece of canvas and tie it with line or your belt.

**Lost Rudder.**—Make an emergency steering device by using buckets, deck covers or anything you can tie to a line and drag behind your boat. By shifting the line from side to side, as shown in the illustration, you can control your direction fairly well. This make-shift rig is called a sea-anchor, and works well if used properly.

**Engine Oil Leak.**—Simply catch the oil in a pan or bucket and pour it back into the engine.

**Complete Electrical Failure.**—To get the engine running disconnect all the electrical equipment from the battery except the large cables from the battery to the starter. Connect a length of wire from the battery post (Positive or large post) to the coil primary switch side and start the engine by grounding the small terminal on the starter solenoid with a screwdriver. To stop the engine disconnect the coil wire.

In most cases you will not be able to proceed at high speed while nursing a sick engine but the important thing is getting into port where permanent repairs can be made.

## stay afloat

Let us now look at some of the causes for "TAKING ON WATER."

The sea around your boat is always looking for a way to get in.

You may find a large quantity of water in the bilges. Your first thought is that the boat is sinking and all is lost.

Don't abandon yet! Have lifesaving devices out and signaling and survival gear ready, but let's look around. Maybe there is a simple explanation for all that water in the boat.

Most boats have openings in the hull that are very necessary to the operation of the craft.

Some of these openings are:

1. Engine cooling water suction
2. Head suction and discharge
3. Galley drain
4. Bail pump supply
5. Propeller shaft, with packing

Any of the above items could be leaking. Check them all and any other hull fittings you know of.

The engine cooling water line may be broken (a common occurrence). While the engine is running it may be pumping the boat full of water.

While checking the hull fittings be looking for damage to the hull. If damage is found you can still save the day by using some good old common sense.

Stuff blankets or a pillow into a damaged area. Wedge them down with a deck cover or paddle. Tear off a railing if necessary to make repairs; a damaged boat is better than no boat at all.

Get underway if possible and head for the nearest land or other boats.

If you must abandon, stay together, keep everyone calm. Use a length of rope to connect all survivors together facing each other. This position will give the most buoyancy and will help keep the group warm and in good spirits until help arrives. Stay with the boat. Most boats will not completely sink; instead will reach equilibrium with the decks awash, with the bow or stern on the surface or may capsize with the underwater body remaining on the surface. The best procedure is usually to stay with the boat until help arrives. Not only will you have

something to hang on to, but you will be more easily spotted by searchers.

## DISTRESS SIGNALS

There are many means of signaling that your boat is in distress.

A recognized small boat distress signal is made by slowly and repeatedly raising and lowering both arms outstretched at sides.

Other signals are: Continuous sounding of fog signal apparatus, flying boat's ensign upside down, a controlled fire aboard boat, rockets or flares. The signal by radiotelephone is spoken word "May day" (extreme emergency only) broadcast on 2182kHz.

Additional information on distress signals are contained in the "Recreational Boating Guide" (CG-340), sold by the Superintendent of Documents, Government Printing Office, Washington, D.C. 20402. Besides distress signals, this publication contains information on various subjects including life saving devices and Federal boating requirements to name a few.

## recommended basic tools and parts

A few basic hand tools and spare parts are a must for every boat. This list will give you some idea of what to have, but many more tools and parts, especially tools of special nature for your engine, should be carried aboard.

**The Test Lamp.**—The test lamp is handy as we have seen on page two. To make it, simply purchase a socket to fit the bulbs used on your boat and attach two lengths of wire about six feet long. Clean one inch of the ends for test prods. Make sure the bulb is the same voltage as the electrical system, i.e., 6 volt, 12 volt, etc.

**Hand Tools.**—Common adjustable wrenches are best for the average small job. Some of them are:

1. Adjustable end wrench (crescent)
2. Slip joint pliers
3. Pipe wrench
4. Vise grip
5. Screw driver (Various sizes)
6. Box end wrench set
7. Hammer
8. Firing indicator—Champion Spark Plug No. CT-436

**Spare Parts.**—This is a list of basic spare parts:

1. Points for distributor





2. Condenser-Rotor-Dist. cap
3. Coil
4. Spark plugs
5. Fuel pump
6. Fuel filter and gasket
7. Drive belts
8. Sea pump impeller

#### **EXTRA PROTECTION**

We have discussed some of the things that can be done if problems come up while you are out on the water. What can be done to help prevent these problems from ever coming up? Following manufacturer's recommendations and keeping your boat and engine in good repair will help to make your boating trouble free.

To find out if your boat meets the highest standards of safety and has all the legally required equipment, ask a qualified member of the Coast Guard Auxiliary for a Courtesy Motorboat Examination.

This examination is free and there is no obligation. It covers all legally required equipment. In addition, your boat is checked for safety practices that are not required by law. If your boat passes, you will receive an official Examination decal. If it does not pass, no report is made to any law enforcement authority. The examiner will advise you of deficiencies so that you can correct them.